



# The International Association for the Properties of Water and Steam

Dresden, Germany  
September 2016

## Technical Guidance Document: Application of Film Forming Amines in Fossil, Combined Cycle, and Biomass Power Plants

© 2016 International Association for the Properties of Water and Steam  
Publication in whole or in part is allowed in all countries provided that attribution is given to the  
International Association for the Properties of Water and Steam

*Please cite as: International Association for the Properties of Water and Steam, IAPWS TGD8-16,  
Technical Guidance Document: Application of Film Forming Amines in Fossil and Combined Cycle  
Plants.*

This Technical Guidance Document has been authorized by the International Association for the Properties of Water and Steam (IAPWS) at its meeting in Dresden, Germany, 11–16 September 2016. The members of IAPWS are: Britain and Ireland, Canada, Czech Republic, Germany, Japan, New Zealand, Russia, Scandinavia (Denmark, Finland, Norway, Sweden), and the United States of America. Associate Members are Argentina and Brazil, Australia, Egypt, France, Greece, and Switzerland. The President at the time of adoption of this document was Professor Hans-Joachim Kretzschmar of Germany.

### Summary

This Technical Guidance Document addresses the use of film forming amines in the water/steam cycles of fossil, combined cycle, and biomass power plants.

In order to control corrosion throughout the water/steam circuits of fossil and combined cycle / HRSG plants, it is essential for the operator of the plant to choose and optimize a chemical treatment scheme that is customized to that plant. IAPWS has provided guidance on the use of volatile treatments as well as for phosphate and caustic treatments; this document addresses the use and application for the range of chemicals referred to as film forming amines (FFA). As well as providing background information on FFA, the document includes guidance in Section 8 for determining if a FFA should be applied, the tests required before application, the locations for the addition, the optimum dosage level, and the tests to determine the benefits of applying FFA. It is emphasized that this is an IAPWS guidance document and that, depending on local plant requirements, the application of FFA will need to be customized (Section 9) for each plant depending on the actual conditions of operation, the equipment and materials installed, and the condenser cooling media.

This Technical Guidance Document contains 43 pages, including this cover page.

Further information about this Technical Guidance Document and other documents issued by IAPWS can be obtained from the Executive Secretary of IAPWS (Dr. R.B. Dooley, [bdooley@structint.com](mailto:bdooley@structint.com)) or from <http://www.iapws.org>.

## Contents

|    |  |    |
|----|--|----|
| 1  | Nomenclature and Definitions.....  | 3  |
| 2  | Introduction: Purpose of Document and How to Use It.....   | 5  |
| 3  | Terminology.....   | 6  |
| 4  | Introduction to Film Forming Amines (FFA) and Film Forming Amine Products (FFAP).....                            | 7  |
| 5  | Background Information.....  | 8  |
|    | 5.1 Definition of Film Forming Amines.....   | 8  |
|    | 5.2 Application.....   | 9  |
|    | 5.3 Advantages and Benefits.....   | 9  |
|    | 5.4 Disadvantages / Critical Aspects.....  | 10 |
|    | 5.5 Basic Properties / Mode of Action.....   | 11 |
|    | 5.6 Monitoring Concepts.....   | 14 |
|    | 5.7 General Suggestions on Legal Compliance.....   | 16 |
| 6  | Description of Applications.....   | 16 |
| 7  | Chemistry Limits.....  | 16 |
| 8  | Operational Guidance for Continuous Addition of a FFA or FFAP.....   | 17 |
|    | 8.1 Evaluating the Potential Benefits and Side Effects of Adopting a Plant Chemistry Program using FFA/FFAP..... | 18 |
|    | 8.2 What does an Operator need to do before Applying a FFA/FFAP?.....  | 20 |
|    | 8.3 Determining Product Dosage Levels and Initial Usage of a FFA/FFAP... ..                                      | 23 |
|    | 8.4 How and Where to Dose the FFA/FFAP.....  | 25 |
|    | 8.5 How to Analyze the Content of FFA within the Cycle.....  | 26 |
|    | 8.6 Determining Optimum Usage.....   | 27 |
| 9  | Customization.....   | 28 |
|    | 9.1 General Comments on FFA Chemistry Differences.....   | 29 |
|    | 9.2 FFA in Combinative Mixtures.....   | 29 |
|    | 9.3 Influence of Unit Pressure and Temperature.....  | 30 |
|    | 9.4 Application to Multi-Pressure Combined Cycle / HRSG Plants.....  | 30 |
|    | 9.5 Systems with Copper-Containing Materials (Fossil Plants with Mixed-metallurgy Feedwater Systems).....        | 31 |
|    | 9.6 Systems Containing Aluminum.....   | 32 |
|    | 9.7 Systems with Air-Cooled Condensers (ACC).....  | 33 |
|    | 9.8 Units with Seawater Cooling and Desalination Equipment.....  | 33 |
|    | 9.9 Shutdown and Layup.....  | 35 |
|    | 9.10 Systems Containing Condensate Polishing Plants (CPP).....   | 37 |
|    | 9.11 General Comments on Industrial Power Plants.....  | 38 |
| 10 | Bibliography and References.....   | 39 |

## 1. Nomenclature and Definitions

| <b>Term</b>                                 | <b>Alternative or Acronym</b>                            | <b>Definition</b>  |
|---|--|--|
| Air-Cooled Condensers                       | ACC  | System to condense steam from a turbine by direct air cooling  |
| All-Volatile Treatment                      | AVT<br><br>AVT(R)<br><br>AVT(O)                          | Conditioning regime in which only volatile alkalizing agents are added to the feedwater (commonly ammonia, but volatile amines may also be employed)<br><br>May be either:<br>Reducing conditions (added reducing agent)<br>or<br>Oxidizing conditions (residual oxygen present) |
| Alkalizing Amine                            | Neutralizing Amine                                       | Amine added to the water / steam cycle to raise the pH in the water and steam phase  |
| Chemical Abstracts Service Number           | CAS-No.  | Internationally used number to identify chemical substances  |
| Condensate                                  |  | Water that derives from condensation of steam after expansion in a steam turbine and passage through a condenser or process heat exchanger   |
| Condensate Polishing Plant                  | CPP  | System containing ion exchange resins to purify condensate. Can also include a filtration system   |
| Condensate Pump Discharge                   | CPD  |  |
| Conductivity                                | Specific Conductivity<br><br>Direct Conductivity         | Electrical conductivity of the water sample as measured directly [1]   |
| Conductivity After Cation Exchange          | CACE<br><br>Cation Conductivity<br><br>Acid Conductivity | Conductivity of a water sample after passage through a strongly acidic cation exchanger in the hydrogen form   |
| Caustic Treatment                           | CT   | Involves addition of NaOH to the boiler or HRSG evaporator   |
| Degassed Conductivity After Cation Exchange | Degassed Cation Conductivity<br>DCACE                    | Conductivity after cation exchange of a sample from which volatile weak acids (predominantly carbonic acid) have been stripped   |
| Dissolved Organic Carbon                    | DOC  | A convenient measure of dissolved organic components in the water or steam   |
| Feedwater                                   |  | Water that is being pumped into a boiler or HRSG to balance the steam production   |

| <b>Term</b>                   | <b>Alternative or Acronym</b>       | <b>Definition</b>   |
|-------------------------------|-------------------------------------|---|
| Film Forming Amines           | FFA                                 | Amines added to the water / steam cycle to form a hydrophobic film on the internal surfaces   |
| Film Forming Amine Product    | FFAP                                | Commercially available FFA material   |
| Film Forming Product          | FFP                                 | Includes FFA, FFAP and other compounds not based on a film forming amine  |
| Flow-accelerated Corrosion    | FAC                                 | Accelerated corrosion of carbon steel components in fossil plant feedwater systems and HRSG evaporators and economizers as result of the flow-induced thinning of the protective oxide (magnetite) on surfaces. |
| Heat Recovery Steam Generator | HRSG                                | Plant that generates steam using heat transfer from the exhaust gas of a combustion (gas) turbine   |
| Once-through boiler or HRSG   | Benson Boiler                       | Boiler in which output steam is generated from input water by complete evaporation. There is no recirculation of boiler water.  |
| Oxygenated Treatment          | OT<br>Combined Water Treatment, CWT | Conditioning regime in which alkalizing agents and oxygen are added to the feedwater  |
| Phase-transition Zone         | PTZ                                 | Region in low pressure steam turbine where superheated steam changes to moisture  |
| Phosphate Treatment           | PT                                  | Conditioning regime for drum boilers in which alkalinity is achieved by dosing a sodium phosphate compound or blend of compounds to the boiler water  |
| Total Organic Carbon          | TOC                                 | A convenient measure of total organic components in the water or steam  |

## 2. Introduction: Purpose of Document and How to Use It

The purpose of this IAPWS Technical Guidance Document (TGD) is to provide guidance on the application of Film Forming Amines (FFA) to assist conventional fossil, combined cycle / HRSG, and biomass plant operators in choosing, applying, monitoring, and ensuring optimum usage of these chemicals in minimizing the risk of possible equipment damage and loss of efficiency, and in maximizing plant reliability. Section 8 contains this guidance. Section 9 indicates how to customize the guidance to many different plants. The guidance is not applicable to nuclear plants. The other sections provide important background information.

This TGD must not be taken as IAPWS support for any commercial products. The guidance document can form the basis of, but should not restrict, other derivative guidelines around the world.

Previously, IAPWS has published a number of Technical Guidance Documents (TGDs) for fossil and combined cycle plants [2-7]. These provide guidance for instrumentation/control, volatile treatments (AVT and OT), phosphate and caustic treatments (PT and CT), steam purity, corrosion product sampling and monitoring, and carryover. Using these TGDs, the development of optimum cycle chemistry guidance can be achieved for fossil and combined cycle / HRSG plants as well as for biomass plants. Each TGD contains a number of base cases for the most common plant configurations and equipment; importantly, the documents also include a number of customizations that should be made for each plant.

This TGD includes new guidance for the application and use of film forming amines (FFA) and film forming amine products (FFAP), which are being applied to fossil, combined cycle, and biomass plants worldwide. There is currently much concern and confusion about their application for continuous operation as well as for shutdown/layup protection. It should also be noted that there is currently very little experience of their use in ultra-supercritical fossil plants. This TGD includes not only some of the important scientific background but also the key guidance steps in Section 8 for applying FFA to these plants, and a number of customizations to the base case in Section 9. These are not applicable to nuclear plants.

It is emphasized that this is an IAPWS Technical Guidance Document representing the cumulative experience of the IAPWS Power Cycle Chemistry (PCC) Working Group (with representation from 21 countries), and as such should be regarded as consensus guidance for the application and usage of film forming amines (FFA) in fossil, combined cycle, and biomass plants. This IAPWS TGD must not be taken as IAPWS support for any commercial products. Section 8 of this document provides guidance for the user/operator on determining if these products can be applied to a plant, how they should be applied and monitored, and the procedures that can be used to determine the benefits of the application. This guidance document can form the basis of, but should not restrict, other derivative guidelines around the world from equipment manufacturers and chemical supply

companies. Experience has indicated that, depending on local requirements, the normal or target values for volatile, phosphate, and caustic treatments presented in the tables of the previous TGDs [4, 5] will provide good reliability and plant availability if they are customized for each plant depending on the actual conditions of operation, the equipment installed, the materials used in different parts of the cycle, and the condenser cooling media.

It is emphasized that, although this TGD provides guidance for the application of FFA to these plants, the IAPWS guidance should not be considered as manufacturer's or chemical supply company's guarantees. Each manufacturer and supplier should provide guidance representing the plant as designed and the FFA chemical composition as manufactured, and these may be slightly different than the operating guidance provided in this document. Also, Section 9 of this document provides a number of customizations for varying plant designs, equipment, and materials.

Although FFA are applicable to industrial steam raising plants, it should be noted that these plants are not covered in detail within this IAPWS Technical Guidance Document. A few general comments, however, are included in Section 9.11. It should also be mentioned that FFA are frequently used for the conditioning of closed cooling or heating systems, but that application is not included in this TGD.

### 3. Terminology

IAPWS recognizes that film forming compounds have been cited in the literature as both chemical substances with specific hydrophobic film forming properties, and commercial products containing these chemical substances. As this may lead to misunderstandings, this Technical Guidance Document uses the following terminology:

- Film forming amines (FFA): defined group of organic substances with specific functional groups. Because the chemical definition covers a wide range of amine molecules, this TGD lists three substances, which have been the subject of intensive research, and where significant application experience is available. The nomenclature of organic molecules can lead to different substance names. Therefore, the three FFA are defined with a unique numerical identifier assigned by Chemical Abstracts Service (CAS):

|                        |        |          |           |
|------------------------|--------|----------|-----------|
| Octadecylamine         | (ODA)  | CAS-no.: | 124-30-1  |
| Oleylamine             | (OLA)  | CAS-no.: | 112-90-3  |
| Oleyl Propylenediamine | (OLDA) | CAS-no.: | 7173-62-8 |

- Film forming amine products (FFAP): Commercially available products which contain a FFA but can also contain further substances such as alkalizing amines, emulsifiers, reducing agents, and dispersants (e.g., polycarboxylates). The operator will need to ask the supplier of the commercial product whether the FFA is included in the listing above.

Examples of alkalizing amines are listed below. They are defined with a unique numerical identifier assigned by CAS:

|                                   |          |          |
|-----------------------------------|----------|----------|
| 2-Aminoethanol (Monoethanolamine) | CAS-no.: | 141-43-5 |
|-----------------------------------|----------|----------|

|                          |          |           |
|--------------------------|----------|-----------|
| Cyclohexylamine          | CAS-no.: | 108-91-8  |
| 2-Amino-2-methylpropanol | CAS-no.: | 124-68-5  |
| 2-Diethylaminoethanol    | CAS-no.: | 180-37-8  |
| Morpholine               | CAS-no.: | 110-91-8  |
| 3-Methylpropylamine      | CAS-no.: | 5332-73-0 |

- Other film forming products (FFP): Commercially available products with film forming properties which do not contain film forming amines.

At this time, this IAPWS TGD only includes guidance for FFA and FFAP.

#### **4. Introduction to Film Forming Amines (FFA) and Film Forming Amine Products (FFAP)**

IAPWS TGDs [2-7] are applicable for most fossil, combined cycle, and biomass power plants and for the conventional treatment methodologies of volatile (AVT and OT) and solid alkali (PT and CT). Alkalizing amines have been applied worldwide as extensions to these treatments or as standalone treatments. More recently, film forming amines (FFA) have been introduced into the market and their use is continuing to increase. Unfortunately, because there are no international guidelines or limits for successful application for these chemicals, there has been much misunderstanding and confusion for the operators of exactly what these chemicals can achieve when applied. In some cases, there has been damage and failure of generating equipment due to misapplication and/or lack of monitoring and control. If plants have not previously made thorough assessments of the chemistry used, the consequences of using a FFA/FFAP cannot be clearly demonstrated. This IAPWS TGD is aimed at filling this gap and providing answers to the most common and most important questions asked by plant operators.

The technology provided in this TGD is applicable to fossil, combined cycle, and biomass power plants.

##### **Objectives of this TGD**

- To provide guidance on whether a FFA/FFAP can be used and is an option for a particular fossil, combined cycle, or biomass plant;
- To provide guidance on how to choose a FFA/FFAP for a particular situation (operation or shutdown);
- To provide guidance on how to use, optimize, and monitor FFA/FFAP in fossil, combined cycle, or biomass plants;
- To consolidate the knowledge and experience gained from using FFA/FFAP in the 21 countries associated with IAPWS;
- To provide initial general advice and suggestions for application in industrial steam generators.

## **Questions and Confusion Associated with the usage of FFA/FFAP (e.g., possible technical risks)**

As already mentioned, there is currently confusion and no international guidance on deciding whether to use a FFA/FFAP and whether there will be any consequences, impacts, or influences on plant operation.

Some of the key questions being asked internationally and that will be addressed within this IAPWS TGD include the following:

- What are FFA/FFAP and what can they accomplish for fossil, combined cycle, and biomass power plants? (See Section 5)
- What may be the consequences of moving from the conventional treatments of AVT(O) and AVT(R)? (See Section 8.1)
- Is FFA/FFAP treatment compatible with other treatment programs? (See Section 8.1.1)
- What needs to be monitored before application of FFA/FFAP (how to conduct a baseline test to determine whether any benefits will accrue)? (See Section 8.2)
- How to monitor and control FFA/FFAP treatment. (See Sections 5.6, 8.3, and 8.5)
- How to determine if the FFA/FFAP is successful and providing the intended benefit. (See Section 8.6)

## **5. Background Information**

This section provides some of the available background information relating to film forming amines. It is intended to give a fairly comprehensive survey of the available scientific information, such as the recent report on FFA in the water/steam cycle [8], and of the application experiences. The literature cited in this TGD has been selected for this purpose but does not claim to be exhaustive.

### **5.1 Definition of Film Forming Amines**

Film forming amines (FFA), which are a family of chemical substances, are misleadingly referred to as fatty amines or polyamines [9-11]. Polyamines are molecules with a saturated carbon chain containing more than three (poly) amino groups. The term “fatty amine” refers to the fact that this group of chemicals is derived from fatty acids [12]. So the term polyamine refers to the nomenclature of the molecular structures, fatty amine describes the derivation of the compounds, and the term “film forming amine” describes the characteristics of the substances. Film forming amine, polyamine, as well as fatty amine summarize a group of organic molecules which overlaps partially, but their definition is completely different. Film forming amines typically contain the following functional groups:

- One or several primary and/or secondary amine groups
- Aliphatic carbon chain (10 to 22 carbon atoms long), saturated or unsaturated.



This TGD is referring only to the substances listed in Section 3, which have been the subject of intensive research and where significant application experience is available. The information and suggestions given in this TGD should not be directly transferred to other substances.

## **5.2 Application**

Film forming amines are solid or paste-like materials and they are sparingly soluble in water. They are applied as solutions, emulsions, or suspensions in water and can be blended with alkalizing substances, such as ammonia, alkalizing amines, sodium hydroxide, or phosphate. The dosage can be as a single component or as a blend of different substances.

The objectives of a FFA treatment include:

- Corrosion reduction in continuous operation;
- Minimization of corrosion product transport;
- Formation of clean, smooth heat transfer surfaces;
- Corrosion protection during shutdown/layup.

The formation of hard scales such as calcium carbonate or silicates due to poor water purity cannot be prevented, and it is currently not clear whether they can be (partially) removed with a FFA/FFAP treatment.

## **5.3 Advantages and Benefits**

Some of the possible advantages and benefits of using FFA can be delineated as follows:

- Clean and smooth heat transfer surfaces; (Section 5.4)
- Removal of loosely bound existing deposits from heat transfer surfaces and steam turbine blades; (Sections 5.4 and 5.5)
- Insensitivity to load transients, frequent start/stop operation, and during shutdown periods; (Section 9.9)
- Improved wet and dry conservation during shutdown/layup; (Section 9.9)
- Lower sensitivity during upset conditions, e.g., contaminants, pH excursions; (Section 9.2)
- Possible lower corrosion products, e.g., in feedwater; (Section 8)
- Reduction of FAC, especially two-phase FAC in HRSGs and ACCs; (Sections 8.2, 9.4, and 9.7)
- Lower corrosion products during startup; (Section 9.4)
- Applicability to many different systems; (Section 9)
- Improvement of heat transfer (Section 5.5).

Some of these are discussed further:

### **FFA as Corrosion Inhibitors**

The inhibitor effect is accomplished by the formation and maintenance of a very thin non-wettable film on the surface of the power plant equipment. The film acts as a barrier between the metal surface and the water/steam phase. Several reports are summarized in [13-16] which show that FFAP have an impact on several corrosion mechanisms. Laboratory test data as well as field tests have demonstrated that for uniform and localized corrosion (flow-accelerated corrosion, crevice [17] and crud-induced corrosion [18]) FFA/FFAP may have a protective effect. Furthermore, reduction of tube failures has been reported in practical applications [19, 20].

### **Supporting the Formation of the Metal Oxide Layer**

In all power generation applications where metal surfaces are exposed to water/steam, there will be a protective oxide layer which will vary in composition **dependent on the equipment material and the operational conditions**. FFA adsorb onto the metal oxide surfaces and thus form a physical barrier between the metal oxide/deposit and the water or steam, providing additional protection for fossil, combined cycle, and biomass power plants, and also other industrial plants.

### **Reduction of Corrosion Product Transport**

The impact of a FFA-based treatment on corrosion product transport can be monitored by quantitative and qualitative criteria. The measured iron and/or copper levels at key sampling locations should be reduced or at least kept on the same level compared with the previous treatment (see Sections 8.2 and 8.6). Inspections of the system should result in improved cleanliness and appearance of the systems. A simple test for hydrophobicity during downtime inspections can be an indicator of general corrosion protection in a particular area of the system. The use of other methods, including corrosion coupons, can help determine on-line / off-line effectiveness.

Due to the interaction of the amino groups with oxides, FFA will gradually remove loose material (corrosion products) from metal surfaces and provide cleaner surfaces. This oxide transport has been reported in many practical applications [21, 22].

### **Other Benefits**

FFA may provide **improved protection** during normal operation and limited short-term benefits during abnormal operational circumstances. These conditions could be ingress of contaminants, from the demineralized water plant due to malfunction during resin regeneration or from surface water condenser leakage. Both require immediate action to minimize asset damage. It should be noted that **the limits of protection strongly depend on the specific conditions**.

## **5.4 Disadvantages / Critical Aspects**

Some of the disadvantages for FFAP can be delineated as follows:

- Thermal degradation and formation of low molecular weight organic acids and the risk of masking anionic contamination (such as chloride and sulfate from a condenser leak) measured by CACE in condensate, feedwater, and steam;
- Lack of knowledge on the impact on condensate polishing plants (see Section 9.10);

- Lack of knowledge on the impact on reverse osmosis (RO) (see Section 8.1.2).
- Incomplete scientific knowledge;
- Risks related to overdosage.

Some of these are discussed further:

### **Degradation Products (See also Section 5.5)**

Organic substances such as FFA and organic components in FFAP are susceptible to thermal degradation at high temperatures. This results in low molecular weight organic impurities, mainly organic acids and carbon dioxide. It is known that both can reduce the pH of condensed steam, and, if this is not compensated for by a proper water treatment program, a higher rate of corrosion may occur, including stress corrosion cracking [23].

The impact of low molecular weight acids on corrosion due to possible pH reduction has been investigated. It was concluded that the specific corrosion effect of organic acids and carbon dioxide is less relevant for real service condition if the local pH is maintained sufficiently [23]. However, these acids can lead to increased level of CACE, which is discussed in the next section.

### **High CACE**

FFA/FFAP under boiler/HRSG conditions are susceptible to thermal degradation, and the low molecular weight organic acids will contribute to CACE. Their application (together with alkalizing amines) may lead to CACE levels that are higher than the suggested IAPWS Steam Purity limits [6] and the guidance set by the steam turbine manufacturers.

FFA/FFAP may also temporarily increase the CACE by enhancing the release of impurities accumulated inside the surface oxide layers. This effect is also often seen when changing chemistries, for example from AVT(R) to OT.

### **Overdosing**

The dosing and control of the FFA and FFAP are critical aspects (see Sections 8.3 and 8.4 for guidance). The key to the control of freely available FFA is to keep its concentration constantly low. Several physical properties of the aqueous phase will change when micelle formation begins at the critical concentration [24, 25]. It has also been reported that constant overdosing of FFA can lead to the formation of “gunk” balls (clumps of gel-like material) which have the potential to form blockages of vessels or tubes [19, 26].

## **5.5 Basic Properties / Mode of Action**

### **Alkalinity**

FFA, as all amines, are bases and therefore increase the pH and conductivity by dissociation in water. Due to the low concentration of FFA required, the impact on pH and conductivity is negligible compared to alkalizing agents (ammonia, alkalizing amines, etc.) [27, 28].

## **Adsorption**

The intended effect of FFA is the strong adsorption on the metal / metal-oxide surfaces [13, 28-30] by a combination of physical and chemical bonding, and thus modification of the surface properties.

The adsorption takes place on metal surfaces including steel, copper, and stainless steel. The results of studies suggest a rapid initial adsorption of a very thin layer (mono molecular layer) followed by a second slower adsorption step and the formation of a multilayer. The amount of FFA adsorbed onto the surface is dependent on the FFA molecular structure, temperature, and composition of the surface [31, 32]. The adsorption isotherm has been described with the Langmuir model [30], whereas the Henry model has been applied in other studies [29, 33].

Furthermore, FFA adsorbs onto metal oxides as has been indirectly demonstrated [34]. Suspensions of magnetite particles and stainless steel particles were cationically stabilized over a broad pH range, as shown by zeta potential measurements. At low concentration of FFA a reduction of magnetite deposition occurs, whereas at high concentrations a coagulation of the particles can be observed, illustrating the importance of avoiding overdosing of the FFA.

It is generally accepted that the long alkyl chain forms a hydrophobic barrier between the metal / metal-oxide surface and the water. The corrosion protection has been studied by electrochemical techniques as well as the film formation, demonstrated by characteristic two-loop Electrochemical Impedance Spectra [14-16, 35]. The hydrophobic barrier film has been confirmed on the surface of laboratory samples by spectroscopic methods, especially Infrared and Photoelectron Spectroscopy [25, 30, 36, 37], and on samples from water/steam cycles [38, 39].

FFA can also adsorb on many plastics and glass surfaces, which has to be taken into consideration for analysis by grab samples. It may also adsorb onto surfaces of on-line instruments and compromise measurements (see Sections 5.6 and 8.1.4).

## **Stability of the Film**

The durability of the film under the different conditions encountered in the water/steam cycle is not completely understood, but practical experience shows that a system with an established film is protected for a shutdown period of approximately two weeks under wet storage.

Several studies in the laboratory under controlled conditions are available on the corrosion protection of FFA. The film formed on the metal / metal-oxide surface is stable and not significantly removed from stainless steel, carbon steel, and copper after several days of exposure to oxygenated FFA-free de-ionized (DI) water [13]. Exposed surfaces showed no sign of corrosion. A sharp reduction was reported of the corrosion rate by ODA in DI water [40] both for metallic blank samples and samples with an oxide layer. Furthermore, corrosion under slightly acidic conditions (oxygenated water at 80 °C) was significantly reduced for a steel specimen prefilmed with FFA compared to untreated ones. Prefilmed steel coupons were exposed to three different air storage conditions: dry, constant temperature; dry, varying temperature; and humid, varying temperature. In contrast to the

untreated steel coupons, the prefilmed coupons did not show any corrosion after one year of storage [41].

### **Volatility**

FFA are steam volatile, and their volatility depends on their chemical structure with monoamines being less volatile than diamines [39, 42]. Due to their volatility, FFA can protect evaporator surfaces, the condensate system, and the steam turbine at locations with high steam moisture. It is not fully confirmed whether film formation also takes place in areas of superheated steam; sometimes steam circuits are found protected possibly because of the presence of water in the steam during startups and shutdowns.

### **Thermal Decomposition Products**

The thermal stability of two of the three FFA molecules listed in Section 3 in aqueous solution has been studied and published. The thermal effect of ODA starts at a temperature of 80 °C. At temperatures above 450 °C, the molecule completely decomposes to carbon dioxide, methane, hydrogen, and ammonia [24]. ODA also combines to form di- and tri-ODA by elimination of ammonia. OLDA has been reported to be stable at approximately 300 °C. No organic acids, such as acetic or formic acid or lower organic amines, could be detected [40]. The thermal stability of OLDA was also studied with thermogravimetric analysis and pyrolysis gas chromatography mass spectroscopy. The maximum temperature was 500 °C. No evidence of decomposition could be found [43].

Besides FFA, FFAP can contain organic alkalizing agents and dispersants. This makes the prediction of potential degradation products more complex. The thermal degradation of a number of organic alkalizing amines (ethanolamine, morpholine, cyclohexylamine, dimethylamine, and 3-methoxypropylamine) have been systematically studied, and these amines are sometimes used as alkalizing agents in FFAP. It has been found that these amines undergo a cationic as well as an anionic degradation. The main product of the cationic degradation is ammonia, while anionic degradation leads to the formation of acetic and formic acids. Minor breakdown products were propionate and glycolate [44].

The main decomposition products may vary depending on the different components of the FFAP and the system conditions (temperature, pressure, and exposure time). The reported decomposition products are carbon dioxide, small organic acids, ammonia, low molecular weight amines, octadecylamine, and substituted diamines. Minor breakdown products may be propionate, glycolate, oxalate, citrate, and benzene [45].

Besides these studies, some detailed measurement programs were performed using Liquid Chromatography – Organic Carbon Detection (LC-OCD) and ion chromatography (IC) to measure thermal decomposition products in steam generators treated with FFAP [28, 46-48]. The main decomposition products found were carbon dioxide and glycol. Small organic acids were only found in traces and were predominantly acetic acid.

As discussed in Section 8, prior to a new application each FFAP supplier should provide the operator the FFAP decomposition products and, more importantly, the impact of these products on the steam CACE and on the pH of early condensate especially at low steam moisture.

## **Heat Transfer**

FFA form a film on the inner surfaces of the water/steam cycle and thus also on the heated surfaces. Due to their surface active properties, FFA feature a theoretical potential for improving the heat transfer in nucleate boiling near metal surfaces. The intensifying impact of FFA on bubble evaporation was qualitatively demonstrated [34] and quantitatively measured compared to phosphate-based water chemistry [49]. Significantly higher heat transfer coefficients have been determined for FFAP-treated steel tubes compared to phosphate-based treatment.

The heat transfer coefficient was determined on copper surfaces as a function of ODA concentration [50]. An improvement in heat transfer coefficient was measured over the tested concentration range. Furthermore, an improvement of heat transfer was reported in the condensation process [51] due to the improved droplet formation on the hydrophobic surfaces in the condenser.

The influence of FFA on theoretically possible boiling crisis (burn-out) in steam boilers has been studied independently [52, 53]. There was no significant influence of FFAP on the critical heat flux density at 2 bar operating pressure compared to phosphate treatment or without treatment. Both metallic tubes and tubes with a magnetite layer were examined [53].

Subcooled boiling after cold and warm starts was studied over time and as a function of FFA dosage, applying a heat flux density up to 1000 kW/m<sup>2</sup>. The curves for tube temperature and heat flux density as a function of time show the same form for FFAP as obtained during analogous tests carried out with phosphate treatment, or with FFA overdosage.

## **5.6 Monitoring Concepts**

### **Monitoring and control of FFA dosing**

FFAP dose rates should be monitored by measurement of the residual FFA concentration in the sampled water. Different test methods are available to accurately determine the amount of FFA in the water. In Section 8.5 of this TGD, the two most applied methods are described. The FFA residual should be controlled at all available sample points because of the different distribution ratios, volatility, and adsorption/desorption processes. Due to the intended adsorption of the film forming amine on the metal/oxide surfaces, there is no straightforward correlation between the FFA added to the system and the resulting concentration in the water sample. Nevertheless, most FFA and FFAP are dosed as a function of flow.

Control of the cycle chemistry using pH, conductivity, or TOC (total organic carbon) measurement is not accurate enough for monitoring dosing of FFA. However, conductivity or pH can be used to control the dosing of a FFAP that contains alkalizing amines.

Qualitatively, the presence of a film can be demonstrated by the lack of wettability of the metal surface. This is the most common and easiest method to qualitatively detect the FFA on a metal/oxide surface. However, hydrophobicity sometimes cannot be observed, e.g., in

case of a rough surface with porous iron oxide deposits, even though FFA is present on the surface.

### **Total Iron/Copper Monitoring**

In the TGD *Corrosion Product Sampling and Analysis for Fossil and Combined Cycle Plants* [7], sampling strategies as well as several analytical methods are described. The presence of FFA as well as FFAP does not interfere with the analytical methods described in [7] for the determination of total iron/copper, nor do the analytical methods change the FFA/FFAP in the sample. In Tables 6 and 7 of that TGD, AAS (Atomic Absorption Spectroscopy) and ICP-AES/MS (Inductive Coupled Plasma followed by Atomic Emission Spectroscopy or Mass Spectroscopy) are listed as suitable analytical methods. The colorimetric reaction based on ferrozine is not disturbed by FFA/FFAP if a previous digestion step is performed.

### **Conductivity and pH Measurement**

Among the main tools to control the cycle chemistry in general, as well as during dosage of FFA and FFAP, are conductivity and pH measurement. If FFA or FFAP is dosed, the following impacts should be considered:

- Impact of the FFA on the measurement equipment. Laboratory experiments with three different FFAP showed that pH measurement using a glass electrode was not affected [57]. But for some FFAP, the coating effect of the conductivity probe led to drift in the reading. These effects are discussed in more detail in Section 8.1.4.
- pH calculation errors due to unknown composition of FFAP. Temperature compensation of conductivity measurement and pH calculation is discussed in this Section.

The result of a conductivity measurement is always expressed as a temperature-compensated value at 25 °C. Most transmitters use fully automatic temperature compensation models. Such models normally assume a dominant ion pair in the water. For example, a temperature compensation model for “ammonia” expects that only the ammonium ion will be present, besides the dissociated water ions ( $\text{H}_3\text{O}^+$ ,  $\text{OH}^-$ ). FFAP sometimes contain mixtures of alkalizing agents or the FFA is dosed together with ammonia. So, using FFAP leads to a more complex mixture of different ions in the water.

A comprehensive study concluded that temperature conversion models within the range from 25 °C to 50 °C depend only slightly on the chemical composition of the sample. The reason for this is that the quotient of the compensated and temperature-dependent equivalent ionic conductivity of all ions have similar values [54].

However, if conductivity measurement is used to calculate the concentration of an ion, knowledge of the chemical composition is mandatory. For example, pH calculation using differential conductivity measurement is one such application. pH calculation uses the total conductivity and the CACE under the assumption that:

- Only one alkalizing agent is present;
- Contamination concentration is small compared to the alkalizing agent.

Additionally, such a model is only applicable within a narrow pH range from 8.0 to 10.5. FFAP can contain a high concentration of strong alkalizing agents other than ammonia. As mentioned in other sections of this TGD, it is most important to know the concentrations of all alkalizing agents in the dosed FFAP. Only with this information is it possible to apply the calculation model to give adequate accuracy, even in FFAP with mixtures of alkalizing agents [28, 55].

The concentration of freely available FFA in the water/steam cycle is generally small compared to the alkalizing agents and does not influence the calculation model.

## **5.7 General Suggestions on Legal Compliance**

FFA and FFAP are chemical substances or chemical preparations, and thus they are the subject of numerous regulations. When using FFA-based products, it is most important to be in full compliance with all relevant regulations. As these regulations vary from country to country, a detailed description of the regulatory aspects cannot be given in this Technical Guidance Document. Some important regulations cover the following aspects:

- Chemical inventory (e.g., REACH, TSCA);
- “Black” list (e.g., Substances of very high concern);
- Discharge;
- Working safety;
- Food application (e.g., for steam having direct contact with food, such as FDA 21CFR173.310).

It should be emphasized that this list is not exhaustive.

It is most important for the user of FFA and FFAP that the supplier of the product provides all necessary information in order to ensure regulatory compliance of the chemicals applied.

## **6 Description of Applications**

FFA/FFAP can be added to plants for a number of different reasons. This IAPWS TGD is applicable to all-ferrous fossil, biomass, and combined cycle power plants and these represent the base cases. Plants that contain copper or copper-based alloys and other variants are addressed through customization in Section 9. The two main applications that are covered are continuous application when the plant is operating, and the conservation mode when the plant has to go into short-term or long-term shutdown/layup.

## **7 Chemistry Limits**

The IAPWS guidance for plant control limits when using FFA or FFAP is the suite of IAPWS TGDs [2-7]; the chemistry treatment will depend on the individual plant. The use of a FFA or FFAP should not require a change of the IAPWS basic guidance except for the customization that should always be applied to any plant. There will, of course, need to be monitoring and



analysis of the FFA and FFAP before and after an application; this is covered in Sections 8.2 and 8.6 of this TGD.

As already mentioned, the inclusion of other alkalizing amines often causes increases in the CACE especially in steam, which relates mainly to the decomposition products as discussed in Section 5.5. Frequently, FFA are applied in combination with alkalizing amines only. This kind of treatment has been called AVT(F) [28] and its chemistry limits will be those in the IAPWS TGD on AVT(O) [4].

## **8 Operational Guidance for Continuous Addition of a FFA or FFAP**

This section provides guidance for operators when applying FFA/FFAP to generating plants as a supplement to, or as a replacement for, the current chemistry regime. This is the base case for this IAPWS TGD, and it is applicable to all-ferrous fossil, combined cycle / HRSG, and biomass plants. As such, the corrosion product sampling and analysis will only relate to the monitoring of total iron as per the IAPWS TGD [7]. If the plant contains copper alloys, then the base case should be customized through the use of Section 9.5. Other customizations in Section 9 include: a) plants operating with different temperatures and pressures; b) various types of HRSGs; c) cooling water systems containing aluminum; d) plants with chloride contamination including seawater-cooled plants and plants providing steam for desalination; e) plants with air-cooled condensers; and f) others.

As indicated in the IAPWS Steam Purity TGD [6], the type of FFA and the FFAP composition, including its percentage contribution to the commercial product, as used in a plant should be known by the operators. However, in certain cases the active FFA and/or the FFAP composition is considered to be a commercial secret or proprietary information. Without knowing the exact chemical composition and the decomposition products, the plant operator cannot know if any damage or failure might be associated with the applied FFAP. Some suppliers of FFA may have conducted independent materials and performance testing with their particular FFA/FFAP blends that demonstrate their effectiveness in controlling the cycle chemistry as intended by/for an individual/particular plant if applied under the recommended supplier instructions. This does not lessen the need for the supplier to provide the composition of the FFA/FFAP. Information on the toxicity of the product should also be provided to ensure the operator understands any environmental aspects.

It is most important for the plant operator to know which FFA is being applied and also any other compounds (alkalizing amines, dispersants, etc.) included in a blend, the purpose for their inclusion, and the result/benefit expected for the plant. It is also necessary to know of any degradation products and the likely effect they will have on the steam/water cycle limits (IAPWS TGDs [4, 5]). As with any major treatment regime change, there is also a major requirement for an initial assessment of the plant prior to the use of FFA/FFAP (Section 8.2). For example, special care should be taken to develop an understanding of internal deposits on HRSG HP evaporators or conventional boiler waterwalls. Lack of such knowledge and poor monitoring and control can lead to failure, such as under-deposit corrosion (UDC), especially where heavy deposits were not identified or removed by chemical cleaning. This applies for any major change of chemistry and it is not specific for FFA/FFAP treatments.

FFA are surface active and will slowly remove loose deposits, but should not be used as a means of cleaning up heavy deposits in an operating boiler or HRSG because uncontrolled metal oxide transport is a major risk to boiler reliability. The risk of overdosing FFA/FFAP is discussed in Section 5.4. The requirement to understand the level of internal deposits in terms of possible under-deposit corrosion and the need to chemically clean prior to an application of FFA/FFAP is discussed in Section 8.2. Therefore, if the condition of the water/steam cycle is not well known, an assessment prior to application of FFA/FFAP treatment is needed, as discussed in Section 8.2. This baseline assessment is used to evaluate the success of the FFA/FFAP treatment program.

The remaining sub-sections provide direct advice and guidance to the operator of a plant who is interested in changing to a FFA/FFAP treatment.

## **8.1 Evaluating the Potential Benefits and Side Effects of Adopting a Plant Chemistry Program using FFA/FFAP**

The plant operator should ask a series of questions prior to changing to a FFA/FFAP treatment regime. The first and foremost question should be “why is there a need to change?” If the plant is operating successfully within the guidelines of the other IAPWS TGDs [2-7], and particularly meeting the corrosion product transport levels [7], then there should be an associated operating or economic benefit for the plant to change. This could relate to a change in the mode of operation with more starts and shutdowns. For plants that do not operate within the IAPWS TGDs and have high levels of corrosion products, there might be a corporate goal for future improved reliability, better shutdown protection, or long-term layup. In all cases there is a need to determine the possible benefits that will or could accrue and, most importantly, to acquire information relating to the concerns delineated in Sections 4 and 5 of this TGD. Once a decision has been made to consider the use of FFA/FFAP, the important questions are: does the proposed product contain a FFA listed in Section 3 and is the FFAP blended with a neutralizing amine and/or a dispersant? Questions should be asked about the thermal stability of any dispersants contained within the blended product and whether they will be suitable under the operating conditions (temperature and pressure) of the plant. Not asking such questions or not receiving satisfactory answers from the supplier can result in an unknown chemical or chemicals being added to the steam/water cycle. The basic IAPWS rule is that if an unknown chemical with unknown degradation products is used at the plant, then relaxation of normal limits and action levels [4-6] is not allowed. One of the primary goals of this IAPWS TGD is to assist in this understanding.

### **8.1.1 Are FFA Treatments Compatible with other Treatment Programs?**

FFAP can be used as a standalone treatment or in combination with other treatment programs. When a FFA/FFAP-based treatment is applied as a supplement to another treatment program, it is very important for the user to know if there are any incompatibilities and how such incompatibilities could affect the system to be treated.

FFAP may contain a wide variety of different chemical substances, as outlined in the introduction to Section 3 and in Section 9.2. Therefore, it is emphasized that a

general statement of compatibility with other programs cannot be given in this TGD. The supplier of the FFAP should provide this important information. The overriding actions for an operator are to know the composition of the FFAP and to conduct a careful monitoring and assessment of the treatment program.

### **8.1.2 What Effects do FFA have on Plant Equipment and Processes?**

#### **Impact of FFA on Ion Exchange Resins**

Information on the impact of FFA on ion exchange resins can be found in Section 9.10 of this Technical Guidance Document.

#### **Impact of FFA on Reverse Osmosis (RO) Membranes**

Reverse osmosis (RO) can be used for preparation of makeup water. In cases when the condensate is returned to the makeup water treatment plant, there is potential for the FFA to come in contact with the RO membranes. Studies on the impact of FFA on reverse osmosis membranes are not available. The adsorption of the FFA molecule on the membrane could cause membrane fouling. The supplier of the FFAP should provide information on any detrimental effects of the FFA/FFAP in contact with the membrane.

### **8.1.3 Are there Special Safety and Environmental Issues?**

FFA and FFAP are chemicals, and thus they should be handled as described on the Safety Data Sheet (SDS), which should be provided by the chemical supplier. The SDS should be fully compliant with current legislation.

FFA are organic and as such will contribute to the total organic carbon (TOC) and total nitrogen levels associated with the blowdown from the water/steam cycle. FFAP can also contain other carbon- and nitrogen-based materials that can further increase the TOC and total nitrogen content of the blowdown. The discharge regulation has to be taken into account accordingly (Section 5.7).

### **8.1.4 Impact on Functionality of Sensors**

The application of a FFA results in the formation of a protective layer on the equipment surfaces. So, it is expected that the analytical equipment used to monitor and control the water/steam cycle will also be coated. Additionally, field reports described problems with some measuring equipment and concluded the reason to be the coating effect of FFA [56].

Under laboratory conditions [57], the impacts of three FFAP on the following instruments were studied:

- Specific conductivity (SC);
- Conductivity After Cation Exchange (CACE);
- Degassed Conductivity After Cation Exchange (DCACE);
- Calculated pH (differential conductivity measurement);

- pH (ion-selective electrode);
- Oxidation-reduction potential (ORP);
- Sodium (ion-selective electrode);
- Oxygen (Clark-type sensor).

With all three FFAP, no interference was observed for pH, sodium (both ion-selective electrodes), as well as for the Clark-type oxygen probe. Oxidation-reduction potential (ORP) probes were affected by all the FFAP tested, and a coating effect was deemed to be responsible for the loss of sensitivity and the speed of response of the instrument. It has also been observed under laboratory conditions that FFA/FFAP can coat conductivity probes. Three FFAP were tested where one FFAP was based on ODA and two FFAP contained OLDA as the FFA. Two tested FFAP containing ODA and OLDA showed coating effects on conductivity probes. Surprisingly, no such coating effect could be observed with another tested FFAP also containing OLDA as the FFA. It appears that it is not necessarily the FFA alone that can promote filming effects on conductivity probes but the combination with other substances in the FFAP. For CACE and DCACE measurements, the main observation was the early breakthrough of the cation exchange resin. It should be kept in mind that the error due to the coating of the probe for certain applications was negligible. However, the loss of sensitivity as well as response time on ORP probes warrants attention.

Other important sensors for plant operation, such as flow and level measurements, may also be affected by FFA/FFAP, but these effects have not been studied systematically.

### **8.1.5 Complete and Comprehensive Documentation**

The supplier of the FFA/FFAP product has to provide safety information, e.g., SDS, fully compliant with local, regional, and national regulations, and comprehensive technical documentation covering the relevant aspects, e.g., handling, dosage, storage, composition, analytical control, application, and discharge (see also Section 5.7). This documentation should be delivered in the country language or at least in English.

## **8.2 What does an Operator need to do before Applying a FFA/FFAP?**

It is extremely important that the key objectives and performance indicators are identified and monitored prior to and during the application of a FFA/FFAP, just as it is for any major chemistry change on any plant. Historically, this has been the most common missing aspect in the application of film forming products and has led to concern as any improvements and benefits provided by the FFA/FFAP could not be quantitatively validated.

Furthermore, good knowledge of the current plant condition is important, such as the presence of thick porous oxide layers, in order to judge the risk related to the intended change of treatment regime, as mentioned in the introduction to Section 8. Good knowledge of the plant condition as well as careful monitoring and control is essential in order to avoid

failures and damage, as has happened in plants where no prior assessment had been made of such important aspects as deposit loading on boiler waterwalls and HRSG evaporators.

The best way of determining the baseline is through measurement of the key indices for the cycle chemistry, especially total iron (and total copper and/or aluminum if the plant contains these metallurgies) under the conditions of the chemistry before the application of the FFA/FFAP treatment. The key parameters from the IAPWS Instrumentation TGD [3] should be monitored in parallel and recorded. It is recognized that some plants might not have this fundamental level of instrumentation and will only be able to use grab samples. The following locations and parameters should be monitored as a minimum: feedwater pH, oxygen, and CACE; drum pH and CACE; and main, reheat, or HP steam sodium and CACE.

Without the results from the baseline tests, there will be no ability for the plant to validate quantitatively that the addition of a FFA/FFAP has provided any benefit. There could be an improvement or, as in some cases, the key indicators of the plant chemistry could be worse.

Thus, the sampling and analytical facilities for monitoring total iron (and total copper) should be in agreement with the IAPWS TGD for Corrosion Product Sampling and Analysis [7]. IAPWS Target Values have been established for total iron (and for copper in mixed-metallurgy units) at various locations around the cycle. Suggested sampling locations for various fossil and combined cycle plant types are summarized in Table 2 of the sampling TGD [7]. IAPWS Target Values for total iron (and total copper) at some of these sample points are provided in Section 5 of the TGD [7]. The required analytical procedures are also delineated in Section 9 of [7]. The Corrosion Product TGD [7] suggests that the samples be taken only during steady high load conditions that have been maintained for at least 3-4 hours and not at the same time each day. The monitoring should last for at least one month prior to the FFA application to ensure that the metal/oxide surfaces within the various circuits are stabilized in respect to the previous chemistry program. This monitoring will take longer in a cycling plant. The frequency of sampling for monitoring should be considered with once per week as the minimum. Comparison of the measurements of total iron (and total copper) to the Target Values provides baseline values and an indication of the effectiveness or otherwise of the current treatment being applied and to be replaced with a film forming product. The whole monitoring process with examples has been published [58]. Results of the baseline series of tests serve as the starting point from which effects of subsequent changes in treatment (addition of a FFA/FFAP) can be compared and evaluated, both against the baseline readings and the Target Values for optimized treatment programs. In some cases, the Target Values for optimized treatment [7] may not be attained unless all the iron oxides are digested prior to analysis to overcome any FFA–oxide interaction. But even in these instances, improvement, as indicated by lower concentrations of total iron (and total copper) in the cycle, should be observed.

IAPWS also recognizes that a number of organizations worldwide have used on-line monitoring of suspended solids using particle counters with laser diffraction or nephelometric turbidity measurement to provide an indicator of particulate iron. The relationship between online methods and the proven IAPWS TGD [7] methods is poor and plant unit specific. Any online method needs to be carried out in conjunction with a robust

IAPWS TGD-based program. These methods could be used as trend monitoring for before and after application of a FFA/FFAP.

Besides the baseline monitoring of the plant's water and steam circuits as indicated above, the condition of the internal surfaces of boiler waterwalls and HRSG evaporators in terms of internal deposits should be assessed. It is well understood that thick deposits can lead to under-deposit corrosion (UDC). Poorly monitored and controlled applications of FFA/FFAP have led to increased transport of iron in the cycle from these deposits. Applying FFA/FFAP treatment without knowledge of the deposits on the high heat transfer surfaces could lead to problems if the precautions delineated in Section 8.3 of this TGD are not respected. Thus it is suggested, as with any major chemistry change, that samples be removed and analyzed prior to the application, and that consideration be given to chemical cleaning if necessary. The emphasis for this suggestion becomes most important for boilers/evaporators that have already experienced an UDC mechanism [59-61]. An IAPWS TGD [62] covers this aspect comprehensively for HRSG HP evaporators.

Additionally, in regard to inspections of plant prior to application of a FFA/FFAP, the condition of the water/steam cycle should be evaluated and recorded with regard to the following:

- Appearance and color of internal parts and surfaces;
- Amounts of sludge and loose deposits in drums, headers, and deaerators;
- General cleanliness of drums, evaporator tubes, turbine blades, etc., and identification of any tubercles and pits on the internal surfaces of pressure vessels;
- Time needed for startup after shutdowns and layup.

Some other aspects that should be recorded prior to the application of FFA/FFAP which can then be used after the start of an application for direct comparison and of the benefits:

- If the plant has experienced any form of FAC [63], the locations and wear rates should be known and recorded. As a FFA/FFAP will influence the FAC mechanisms in single- and two-phase flow, these will provide important indicators for comparison and of benefits following the application. Positive results have been observed worldwide, especially for two-phase FAC in HRSGs, but usually there has not been any quantification of the damage reduction.
- For units with air-cooled condensers (ACC), the condensate total iron levels should be included in the baseline monitoring. A quantitative indicator of the FAC in the transport ducts and especially at the tube entries in the upper ducting should be known and recorded using the ACC corrosion index (DHACI) [64].
- If there is a condensate polisher in the plant cycle, then the key indicators of performance such as pressure drop should be documented.

It should be emphasized that, without the results from a baseline assessment, there will be no ability for the plant to quantitatively identify benefits and drawbacks of the addition of a FFA/FFAP. Thus, the validation of the new chemical treatment program would have to be based on qualitative parameters only.

### 8.3 Determining Product Dosage Levels and Initial Usage of a FFA/FFAP

As the FFA/FFAP products are currently supplied as proprietary chemicals, it is to be expected that each chemical supplier, even supplying the same basic chemical (FFA) delineated in Section 3, will have product formulation differences and different recommended dosages. This sub-section provides some general guidance for the plant operator.

As FFA are adsorbed as a hydrophobic film onto the available steam/water internal oxide surfaces, the objective of a treatment with FFA/FFAP is to establish as complete a film as possible on these internal surfaces. The required initial dosage is determined by the available surface oxide/deposit area, the surface properties such as porosity and roughness, the concentration of active FFA injected, and the estimated thermal decomposition of the active chemical in high temperature/pressure plants. Because not all of these parameters are known, the exact quantity of FFA needed to establish the protective film cannot be accurately predicted. In many plants the inner surface area of the water/steam cycle can only be estimated. Therefore, the analytical proof of the FFA in the return condensate is used to verify the distribution of FFA. If the dosage is not sufficient, the film formation will remain incomplete.

The control of dosage is carried out via the determination of the residual free FFA in the various samples taken around the steam/water circuit. Dosage of the FFAP has to be adjusted to achieve the specified value in the control samples, predominantly in the condensate. The dosage should be adjusted accordingly if the measured concentration is outside of the specified range.

Following are some of the key features that operators should be aware of in developing an optimum dosage rate and during early operation with a FFA/FFAP:

- For most cycles, it is suggested that the FFA/FFAP is gradually introduced and increased to the target dosage. The initial dosage is usually based on a supplier's laboratory research studies including corrosion, volatility, basicity, etc., combined with practical experience. The results of these should be reviewed with the chemical supplier prior to initial application. This is to make sure that the FFAP to be used relates to the specific plant and to the materials contained within the condensate, feedwater, and boiler/evaporator circuits (all-ferrous or mixed-metallurgy).
- The FFA/FFAP should be fed proportionately to the feedwater (or makeup water) flow by an automatic dosing pump.
- The initial target dosage will probably be at the low mg/L (ppm) level as FFAP based upon feedwater flow. If a power plant is starting a treatment based on FFA, it is quite normal that, for a time dependent on the plant, mode of operation and dosage, no FFA will be detected in the condensate due to the adsorption of the FFA onto the metal / metal-oxide surfaces. The actual product demand will depend on the chemistry treatment (AVT(O), AVT(R), PT, or CT) being used prior to the application of the FFA/FFAP. The period also depends on the operational mode of the plant, i.e., whether it is operating continuously or cycling.

- It must also be noted that for mixed-metallurgy systems with copper alloys there is a large difference between an application of FFA/FFAP to a system which has been operating previously under oxidizing conditions due to poor air in-leakage control (high oxygen levels), and those systems which have operated optimally under reducing conditions with low levels of condensate oxygen as per the IAPWS TGD [4]. Very careful baseline monitoring (Section 8.2) for total copper needs to be conducted for the former case.
- Porous oxides or deposits in the plant could be partially removed from the surfaces by the moderate cleaning effect of the FFA. This is the main reason why it is suggested to begin with a dosage rate that is lower than the estimated final dosage for continuously operating plants. During the initial period of treatment, an increase of particulate iron and/or copper oxides (if copper alloys are included in the cycle) will be measured, indicating the above mentioned cleaning effect. Usually, this effect is limited in duration. The effect of the FFA dosage on the iron and copper must be evaluated after this first cleaning period is finished to make a comparison with the IAPWS TGD on corrosion products [7].
- Following the initial system demand, the feed of the FFA/FFAP should be increased to the desired target (as product) until it is determined that all monitored parameters as delineated in Section 8.2 are stable. This is typically achieved over a period of 3-4 weeks as a minimum in most systems, but it can vary as indicated above with the prior chemistry treatment, the materials of construction, and the operational mode of the plant. The initial target dosage is then maintained contingent on the total iron (and total copper) monitoring levels being less than those in the baseline and/or those target levels in the IAPWS TGD [7]. This typically takes up to three months. If a FFAP is applied without an alkalizing amine, the former alkalizing agent, e.g., ammonia, should be monitored to maintain the desired pH control that is in agreement with the IAPWS guidance [4]. If a FFAP is applied that also contains an alkalizing amine, the pH should be monitored, and the feed of the previously used alkalizing agents can be reduced and/or stopped. The feedwater pH control range should be in agreement with the IAPWS guidance [4].
- It is most important that the total iron (and total copper) concentration be monitored across the cycle using the procedures in the IAPWS sampling TGD [7] with full digestion and as outlined in Section 8.2. This ensures that, in case of large amounts of corrosion products, they are identified by the operator and not allowed to flow around the cycle. In the case of elevated concentrations of corrosion products, the operator may need to reduce or stop the addition rate.
- If necessary, and based on these iron/copper monitoring results, increase the boiler/evaporator blowdown rate to maintain the iron and copper levels within the appropriate control guidelines [7].
- The FFA residual should be monitored using a spectrophotometric test such as discussed in Section 8.5. This test should be performed daily as a minimum until a stable active FFA residual is achieved in the boiler/evaporator feedwater. Also, pH should be monitored continuously.
- An overdosage of FFA for a long period of time must be avoided. Overdosing increases the risk of higher metal oxide transport and the formation of sticky



deposits especially in strainers, filters, steam traps, and small pipes. There will also be a detrimental effect on the condensate polishing plant (see Section 9.10).

- The cycle pH should be corrected, if necessary, with an adjunct feed of ammonia and/or alkalizing amine if used to maintain the feedwater pH within the IAPWS guidance [4].
- Plant operators using a phosphate-based treatment (preferably only PT as per the IAPWS TGD [5]), prior to dosing a FFA/FFAP should maintain the phosphate level during the initial “film-forming amine demand” period [5]. The phosphate addition is continued to maintain internal boiler protection until the FFA protective hydrophobic film is formed. Once the targeted value of FFA residual is achieved and maintained in the feedwater, and FFA is measured in the fossil boiler water or HRSG evaporator water, the phosphate feed may be carefully discontinued. In high pressure boilers/evaporators, the solid alkali may be required for boiler pH management in association with blowdown. In the LP circuits of HRSGs, the phosphate feed is often needed to control two-phase FAC [5, 63] and should be maintained until confirmation that the FAC has been reduced or eliminated by use of the FFA/FFAP.

#### **8.4 How and Where to Dose the FFA/FFAP**

It is generally suggested to feed the FFAP into the system undiluted (i.e., as shipped). If a dilution of the commercial product is desired, the supplier of the chemical should give advice on the stability of such dilutions. For most applications, one single point of feed is adequate to introduce the FFA/FFAP to the cycle with the ideal location being into the condensate at the condensate pump discharge (CPD) or at the condensate polisher plant (CPP) outlet if a CPP is installed on the unit. An alternative feed point is at the boiler/HRSG feedwater pump inlet. In a fossil plant, this will most often be the deaerator outlet. In a combined cycle / HRSG plant, this could be at the feedpump inlet or deaerator outlet if installed, but for units without deaerators the preferred location would be at the feedpump inlet to the LP, IP, and HP economizer circuits. It is also not preferable to add the FFA/FFAP into the drum or steam headers, as the high temperature superheated steam will result in significant thermal degradation of the FFA/FFAP and neutralizing amines contained in the product.

However, FFAP containing non-volatile components such as polycarboxylates, sodium hydroxide, or phosphate must not be dosed into the feedwater because this is the source for attemperation water. In these cases, they should be dosed into the drum.

In the case of plants equipped with an ACC, the dosage or additional dosage of the FFAP into the steam exhausting line from the low pressure turbine to the condenser should be considered in order to directly provide the FFA to the huge iron-containing surfaces of the ACC. A uniform distribution of the FFA in the water/steam mixture has to be achieved.

The chemical feed system must be compatible with the FFA/FFAP product. The following materials are frequently used:

- Teflon membrane;

- EPDM seals;
- Polyethylene and stainless steel tubing.

Due to the variety of materials, this IAPWS TGD cannot give a full list of materials suitable or not suitable to be used in the dosing system. However, incompatibilities have been reported frequently for Viton and for some elastomers. Therefore, it is suggested to avoid these materials, or the supplier of the FFAP should provide the necessary information.

## **8.5 How to Analyze the Content of FFA within the Cycle**

### **Where and How to Sample (Container Material and Storage)**

FFA are surface-active substances; therefore, all sampling lines will be coated as well. It is preferable to have constant sample flow on the extraction line.

If the FFA concentration is measured by a grab sample method, the use of PTFE as the sample storage material together with the addition of acetic acid to adjust the pH will prevent a decrease of FFA concentration over time. Normally, the amount of acetic acid used for this sample pre-treatment is negligible compared to the sample quantity and will not affect the measurement of FFA by dilution. However, unnecessary dilution steps and long storage times should be avoided.

If storage materials other than PTFE are used, they should be silicone coated. If the storage time is relatively short (few hours), typical laboratory plastic materials and glassware are also suitable.

A sample containing a high concentration of FFA should be stored at room temperature. Due to the low water solubility of FFA, cold storage temperatures should be avoided.

Detergents should not be added to increase storage time. Detergents of all kinds strongly interfere with colorimetric methods such as those based on methyl orange extraction or xanthene dyes [58]. Sample vessels which are used repeatedly should be cleaned with solvents in order to remove FFA residues and to avoid cross contamination.

The locations to be monitored include those delineated in Section 8.2 which are the IAPWS TGD suggested locations.

### **Methods of Analysis**

Numerous analytical techniques have been developed for the determination of FFA concentration. The most dominant approaches are those using two different spectrophotometric analyses:

- Methyl orange extraction;
- Xanthene dye reaction.

The methyl orange extraction uses the abilities of long-chain primary amines to form a water-insoluble colored complex with methyl orange. This complex is extracted in an organic solvent (e.g., chloroform, dichloromethane). The concentration of FFA present in

the sample is proportional to the color formation. This method is described in a British Standard document [65].

Xanthene dyes are a class of molecules related to fluorescein. Two examples are Eosin Y (2',4',5',7'-Tetrabromofluorescein disodium salt) and Rose Bengal (4,5,6,7-Tetrachloro-2',4',5',7'-tetraiodofluorescein sodium salt). The sodium salts of the dyes form a water-soluble colored complex with FFA. This complex is measured without further treatment. [66, 67].

The fact that the xanthene dye method does not require a toxic organic solvent makes this analysis easier and safer to handle. Approaches for online measurement of FFA normally use the xanthene dye reaction [68, 69]. The experiences obtained with two prototype on-line monitors in an industrial water-steam cycle have been reported [70].

Both methods described are applicable to the three FFA molecules defined in Section 3.

A commercially available test kit or online measuring system should fulfill the following requirements:

- Expression of the result as a mass fraction (e.g., mg/kg) of ODA, OLA, or OLDA;
- Wide measuring range (avoids dilution steps);
- Detection limit: the method should have a detection limit to measure traces of free FFA. This means a detection limit preferably lower than 0.1 mg/kg as ODA, OLA, or OLDA.
- No interference by short-chain amines (normally present as alkalizing amines) or ammonia.

### **Analysis of decomposition products**

The main anionic decomposition products are short-chain organic acids (acetate and formate) together with carbon dioxide. These breakdown products will increase the CACE and DCACE. A selective measurement of all ionic thermal degradation products can be performed with ion chromatography. These low molecular weight acids may mask the presence of undesirable anionic contamination (e.g., chlorides) identified by the CACE monitoring.

## **8.6 Determining Optimum Usage**

After a FFA/FFAP is applied to a plant, the operator will need as soon as possible to determine whether it is accomplishing the desired effect, and then be able to assess the benefits of the application. This is a crucial process which basically follows on from the baseline monitoring and inspections (Section 8.2), and from the data obtained after the operation of the water/steam cycle with the FFA/FFAP running properly, i.e., the targeted values have been achieved (Section 8.3). Before this, the data can only provide a first indication.

If the baseline aspects have not been determined or the verification step is not completed as the FFA/FFAP is applied, then the operator only has qualitative indicators of success.

Without careful monitoring and control, the operator would have no idea of an arising problem or notice it too late. This could lead to failure and damage, as with any chemistry change in any fossil, combined cycle/HRSG, or biomass plant. Therefore, as outlined in Section 8.2, a second monitoring campaign must be conducted to monitor the new chemistry once a FFA/FFAP is added to the plant. The important aspect is to be able to compare these results directly with those from the baseline series of tests. To accomplish this, the same total iron (and total copper) monitoring protocol as developed for the baseline series of tests should be adopted by monitoring the same locations and parameters around the cycle (Section 8.2). It is suggested that at least three months will be needed to record the total iron (and total copper) levels which can be compared with the baseline tests. Sample lines should be inspected if possible after an extended treatment period and checked for organic/oxide fouling to assist in understanding, disputing, or validating reductions in oxide transport.

As mentioned in Section 7 of this TGD, application of a FFA/FFAP should not be expected to change the major operating chemistry parameter limits for the plant customized from the other IAPWS treatment TGDs [4, 5] or from the OEM's guidance.

At the first opportunity after an FFA/FFAP application, the opportunity should be taken to compare the internal inspection results with those outlined in Section 8.2.

## 9 Customization

As with the other IAPWS TGDs, this customization section is most important so that the IAPWS Guidance in Section 8 can be customized to accommodate a very wide range of plants with different configurations, materials, cycle chemistries, and operating requirements including various shutdown/layup situations. The previous sections of this document have provided general guidance for the base cases of all-ferrous fossil, biomass, and combined cycle power plants, which cover the wide majority of plants around the world where FFA/FFAP will be used. **However, it is emphasized again that this is an IAPWS Technical Guidance Document and that, depending on local requirements, the guidance and analytical processes will need to be adapted and customized for some plants as there cannot be one set which can be applied to every plant worldwide. It is also emphasized that IAPWS does not advocate or support use of any specific commercial FFA/FFAP products in the applications discussed in Sections 9.1 to 9.11.**

This customization step for every plant is very important to ensure that: a) the FFA/FFAP is chosen correctly for that plant; b) baseline testing, monitoring, and inspection is conducted; c) the FFA/FFAP is added at the correct location; d) the optimum level of FFA is added; e) there is adequate instrumentation and monitoring; and f) the benefits and efficacy of the new chemistry is ascertained through a second monitoring program where the results can be directly compared with the baseline. Thus, the emphasis of this section is to provide guidance on steps that the operator must take if the plant is not configured or operated as the base plants in the previous sections of this TGD. The most common of these features constitute the topics in Sections 9.1 to 9.11, which relate to units with mixed metallurgy including copper and aluminum alloys, different temperatures and pressures, plants with seawater cooling or desalination equipment, plants with ACCs, and plants that will be shut down for various

periods. This section also provides guidance on the wide range of FFA combined blends with other neutralizing amines and dispersants.

## **9.1 General Comments on FFA Chemistry Differences**

In general, the predominant and reactive functionality of FFA molecules makes their interaction with the oxide to metal surface non-selective. However, FFA differ in their mechanism of operation and their interaction with the virgin metal, the semi-protective porous oxide, and protective oxide boundaries. The location, mode, and tenacity of protective film formation vary by product, molecular type, their orientation, and respective abilities to isolate a surface from the cooling medium. Some FFA combination products utilize mixtures with other alkalizing amine compounds (Section 9.2), and these additional organic additives not only exhibit different volatile-to-liquid partition ratios to the FFA active compounds themselves, but they also have their own thermal degradation products. Some of the blended products contain dispersants. It is most important that the operator and/or prospective user of FFAP is provided with full disclosure on the composition and compounds of the FFA blend and of the limitations and potential consequences in the steam/water cycle.

## **9.2 FFA in Combinative Mixtures**

FFA can be blended into FFAP with other treatment chemicals that have previously been applied to high pressure boilers and HRSG systems. Such materials sometimes include alkalizing amines (e.g., ammonia, monoethanolamine), reducing agents (e.g., hydrazine, carbohydrazide, hydroxylamines), dispersants (mainly polycarboxylates, e.g., acrylates), and solid alkalizing agents (e.g., sodium hydroxide, alkali phosphates).

FFAP containing non-volatile components such as polycarboxylates, sodium hydroxide, or phosphate must not be dosed into the feedwater because this is the source of attemperation water. They must be dosed into the drum. It should be noted that the thermal stability of polycarboxylates (dispersants) is strongly dependent on their chemistry, and thus it is very important to use a polycarboxylate which is suitable for the conditions (temperature and pressure) in the boiler. The supplier of the FFAP should provide this information accordingly.

FFAPs that are a mixture of the active ingredients listed above can be used in conjunction with other treatment products or as a single, stand-alone “all-in-one” treatment product to protect the whole steam/water circuit. The contents of the FFAP may dictate the application location in the steam/water circuit to ensure effective system protection while maintaining steam purity. There must be discussion on the location and the operator should not simply use the injection equipment and location for the previous and on-going chemistry program. Numerous problems have occurred because insufficient time was spent in ensuring the correct location of addition as discussed in Section 8.4.

The fact that many of these materials are organic and contain varying amounts of carbon in their chemical structure will lead to an increased level of lower molecular weight compounds in the steam/water circuit after exposure to the high temperature/pressure sections of the system. The level to which these compounds will affect steam purity,

particularly conductivity after cation exchange (CACE), will depend on the molecules used, the application location, and the dose rate to achieve the required effect in the steam/water circuit. These effects must be identified by the monitoring programs outlined in Sections 8.2 and 8.6.

### **9.3 Influence of Unit Pressure and Temperature**

The relative volatility, thermal stability, and thermal degradation products of both FFA and FFAP depend on many variables, but predominantly upon the molecular architecture of the chosen FFA and the other compounds in the FFAP, and the thermo-hydraulic conditions. These variables include but are not limited to the effects of pressure, temperature, water quality, contaminant excursions, metallurgies, and oxygen levels. As a general rule, the degradation increases with temperature and residence time. The influence of pressure on degradation is less pronounced and depends on the molecule [44]. It can be expected that degradation takes place predominantly in the superheater and reheater section. Details on the degradation products formed can be found in Sections 5.4 and 5.5 of this TGD. The FFAP should work within the framework of the existing user site treatment protocol.

FFA-based treatment options can work both as a replacement to well-known and established treatment programs documented in international guidelines including the IAPWS TGDs [4, 5], but can also provide a possible additional layer of protection. Local pressures and temperatures will determine the presence and relative ability of FFAP to protect metal. Protection will vary by location and conditions to which they exist in the steam/water cycle. These effects must be identified by the monitoring programs outlined in Sections 8.2 and 8.6, and the requirements within the IAPWS Steam Purity TGD [6] must be adhered to as mentioned in Section 9.2.

### **9.4 Application to Multi-Pressure Combined Cycle / HRSG Plants**

For multi-pressure HRSGs, it is important to note that the temperature and pressure effects in Section 9.3 will be most applicable and that each pressure circuit will need to be monitored according to the guidance outlined in Sections 8.2 and 8.6.

Volatility of FFA and other compounds included in FFAP depend on temperature, and thus their distribution between steam and water phase changes for the HRSG sections with different operating pressures. Special care has to be taken in the selection of alkalizing amines to achieve the desired pH control in drums and steam.

The injection points of the chemicals in combined cycle / HRSG plants have to be carefully selected in order to ensure rapid distribution of all components in the complete water/steam cycle and to achieve stable conditions within a short period of time. Therefore, as discussed in Section 8.4, FFAP dosing should preferably be into the condensate pump discharge or before the main feedwater pump.

Dosing into a boiler drum is not suggested due to the uneven distribution of the components resulting from the differences in volatility. The only exception to this was discussed in Sections 5.2 and 8.4 with regard to FFAP containing non-volatile components and the concern for attemperation if they are dosed in the feedwater. Components with low

distribution ratio will accumulate in the drum, whereas components with high volatility are enriched in the steam phase.

When applying FFA/FFAP to a combined cycle / HRSG plant, the same baseline monitoring and inspection aspects as described in Section 8.2 will need to be conducted prior to application. The key monitoring locations for total iron will be in the feedwater (usually at the outlet of the boiler feedpumps) and in each of the HRSG drums. The instrumentation required and parameter(s) to be recorded will be as delineated in the IAPWS Instrumentation TGD [3]. From a failure/damage point of view, it is important to have recorded the details of any HRSG tube failures. This includes the locations of any FAC (single- and two-phase) so that any improvements can be noted after the FFA/FFAP application, and may also be accompanied by a reduction in total iron corrosion products. If the HRSG has experienced UDC or has extracted HP evaporator tubes with heavy deposits, then particular care must be given to the application of FFA/FFAP in terms of careful total iron monitoring to ensure that there are no increased levels. It may be better operating practice not to dose FFA/FFAP until the root cause of the UDC has been addressed and the heavy deposits removed by chemical cleaning.

## **9.5 Systems with Copper-Containing Materials (Fossil Plants with Mixed-metallurgy Feedwater Systems)**

Generally, the corrosion of fossil plant feedwater copper-based alloys and the transport of copper oxides increases with oxygen concentration (increasing ORP) under AVT chemistry. This involves a continued growth of cupric oxide on the copper alloy as oxide is removed from the surface and the base metal continues to corrode. There is a risk for cupric and cuprous oxide release, transport, and re-deposition in the feedwater and generating sections as well as the threat of possible copper hydroxide (cupric and cuprous) volatilization and transport through the superheater and to the steam turbine. The accepted international protocols for mixed-metallurgy feedwater systems, as outlined in the IAPWS TDG for Volatile Treatments [4], should be applied in order to minimize these risks.

The reactive functionality of FFA molecules is such that the amino group will directly interact with metal ions and their oxidation state (protective or semi-protective oxides). Thereby, a protective layer is formed, which acts as a barrier between the water and the metal / metal-oxide surface and can promote the passivation of the alloy surface. There is a complex formation between FFA molecules and metal / metal oxides that may lead to increased metal-oxide transport in case of overdosing. Therefore, the concentration of FFA has to be carefully determined and monitored as outlined in Sections 8.3 and 8.5 of this TGD.

Although there are indications that the target values for Oxidation-Reduction Potential (ORP) and oxygen concentration of AVT(R) could be relaxed when applying FFAP, the user should respect these and should ensure routine analysis for total copper and copper transport using the protocols and procedures delineated in the IAPWS TGD [7]. It should also be noted that there is serious impact of FFA/FFAP on the ORP measurement (Section 8.1.4) which might preclude its use.

When FFAP containing alkalizing amines are applied for pH control instead of ammonia, the risk of ammonia grooving due to the formation of cupro-ammonium complexes can be significantly reduced.

It is thus extremely important that monitoring campaigns are adopted for baseline conditions (no FFA) and after FFA addition for units with mixed-metallurgy feedwater systems and those with copper alloys such as desalination equipment. For these, total copper must be monitored before and after the addition using the protocols and procedures delineated in the IAPWS TGD [7] and outlined in Sections 8.2 and 8.6.

## 9.6 Systems Containing Aluminum

Cooling Systems with Aluminum Tubes. This customization relates to units with a jet-spray condenser and a dry-cooled heat exchanger tower with aluminum tubes. Units that have these systems require strict pH control to ensure compliance with published guidelines for these metals (see IAPWS TGD on Volatile Treatments [4]). The utilization of FFA formulations that exhibit molecular basicity and especially those with alkalizing amine combinations should be carefully evaluated, not only due to inherent highly alkaline product pH restrictions and limitations of the chemicals dosed, but also the localized pH increase of the film that contacts the oxide-to-metal interface and which could substantially increase corrosion of aluminum alloys. The user should also be aware of the partition coefficients of alkalizing amine combinations that will predominate in the low pressure saturated steam sections and especially in the two-phase potential liquid film FAC locations. Only FFAP that ensure compliance with published guidelines, especially concerning pH, for these metals may be applied with care for aluminum protection in air-cooled condensers. The user should exhibit care and ensure routine analysis for soluble aluminum oxide release, transport, and re-deposition in the feedwater and steam generating sections as well as the possible metallic oxide volatilization and impact on steam turbine integrity [6]. Plants with aluminum cooling systems need to include the monitoring of aluminum in the baseline testing and compare the results to the suggested levels in the IAPWS TGD on Steam Purity [6].

It is known that aluminum oxide/hydroxide has a significant volatility in steam and thus may transport into the steam turbine and deposit on the blade surfaces as the steam expands. Aluminum-based oxides/hydroxides have low solubility and are therefore hard to remove chemically from generator heat transfer surfaces. These concerns are supported by experience of steam turbine fouling in plants that contain aluminum [6].

As there is not a large amount of experience in applying FFA to plants containing aluminum, it will be most important for an operator to conduct a thorough assessment of the equipment around the cycle before application. This should include tube sampling from the steam generating tubes to assess any aluminum deposition. It will also be necessary to monitor total iron and aluminum before and after the addition using the protocols and procedures delineated in the IAPWS TGD [7] and outlined in Sections 8.2 and 8.6.



## 9.7 Systems with Air-Cooled Condensers (ACC)

Unlike water-cooled condensers made of corrosion-resistant alloys like red or yellow metal, stainless steels, or titanium grades, ACC tubes are normally fabricated in carbon steel. They add a vast steel surface area to a water/steam cycle, typically of the order of thousands of square meters, and hence constitute a major potential source of total iron corrosion products.

Furthermore, unlike water-cooled condensers, ACC cannot be placed directly underneath steam turbines. This necessitates the use of relatively long transport lines for the two-phase mixture of water and steam exhausting from the LP steam turbine.

In this case, the dosage of the FFAP into the steam line from the turbine to the condenser can be considered in order to directly provide the FFA to the huge iron surfaces of the ACC. A good distribution (fine spray) of the FFAP in the water/steam mixture has to be achieved, and water should not be allowed to pool.

Conditions both in the transport lines and at the tube entries of the ACC make them susceptible to FAC [63], with the tube entries in the upper ducting operating under the most severe two-phase FAC conditions [64]. If the cycle chemistry control for units with ACCs is not in essential agreement with the IAPWS Volatile Treatment TGD [4] with pH levels close to 9.8, then the international experience indicates that very large levels of total iron will be measured in the condensate and feedwater [64]. Most often, plants operate with condensate filters to assist in the removal of the total iron particulate. There is an ACC Corrosion Index (DHACI) [64] which has been applied to ACCs worldwide so that a unifying indicator can allow qualitative comparisons before and after the application of FFA/FFAP.

It is most important that monitoring of total iron is conducted before and after FFAP application to units with ACCs in accordance with the protocols and procedures delineated in Sections 8.2 and 8.6. These must be accompanied by the application of the DHACI index so that improvements can be easily semi-quantified.

There are few reports on the experiences of applying FFAP in water/steam cycles equipped with ACCs [26, 47, 71]. Good results have been reported following FFAP treatment, but often when FFAP have been added to units with ACCs there has been no baseline comprehensive monitoring of total iron or inspections of the ACC tube entries using the DHACI so this has not allowed an assessment of the improvement after treatment.

## 9.8 Units with Seawater Cooling and Desalination Equipment

The use of seawater cooling for fossil, combined cycle, and biomass power plants always creates a higher risk for damage and failure of major components, so any treatment program has to include operating and chemistry procedures on how to deal with ingress of the contaminant, chloride. Unfortunately, no condenser or condenser material is totally resistant to failure, and the IAPWS TGDs on Volatile [4] and Solid Alkali [5] Treatments cover such events in detail; this is applicable to condenser tubing manufactured in titanium, stainless steel, and copper-based alloys. Some desalination plants include brine heaters,

heated by LP steam, and dump condensers cooled with seawater. The tubes in both cases are fabricated with copper-based alloys (usually Cu/Ni alloys). Multi-effect desalination plants (MED) also mostly rely on copper alloy tubing. Tubes in both desalination systems sometimes leak because it is very difficult to operate with chemistries that provide protection to these copper alloys and at the same time to the all-ferrous materials in the generating source (HRSGs or boilers).

These plants can operate on the chemistries included in the other IAPWS TGDs [4, 5] or on blends of alkalizing amines. They can convert to the use of a FFAP containing alkalizing amines and maybe dispersants. But in all cases it is most important that tubes are removed from the steam generating sections (HRSG HP evaporators and boiler waterwalls) to determine the internal deposits prior to changing the chemistry to a FFA/FFAP so that a chemical clean can be performed if necessary before the conversion. As also discussed in Section 8.2, monitoring is most desirable before the addition, but often in the past has not been accomplished.

The choice of which FFA to use has been covered in Section 8.3 as well as the key questions that need to be asked. The methodology of determining how much FFA to use and how to monitor whether the FFA is successful has also been covered in the base cases of Sections 8.4 and 8.5.

Irrespective of whether the plant is using FFA, the plant operator must always be prepared for a sudden leak of seawater from a condenser or dump condenser or MED tubing, or of concentrating brine from a brine heater. Such major incidents of leakage can cause significant chloride ingress into the boiler/HRSG system. Consequently, the CACE for the condensate, boiler feed water, boiler water, and steam will increase within a very short period of time. However, it should be noted that if the leak is very small then CACE may not be sufficient to identify the leak because of increases in CACE from the application of the FFA/FFAP. IAPWS strongly suggests [3] that these plants also have sodium analyzers in the condensate at the condensate pump discharge (CPD) and in steam. Most importantly, the pH for all boilers/HRSGs will decrease rapidly after the leakage and thus subject the boiler/HRSG to conditions which could lead to under-deposit corrosion. The primary reactions to such a situation have been covered in other IAPWS TGDs [4, 5] and will require the unit to be shut down immediately if the boiler or evaporator water pH continues to decrease below 8.0.

Although the film formed by the FFA provides an additional protection to the surfaces, it must be emphasized that the identification and elimination of the leakage is a priority measure. Longer-term operation outside of the recommended specifications set forth in the IAPWS guidance must be avoided [4, 5]. A major problem with seawater ingress is the deposition of sodium chloride onto the steam turbine. It is known that FFA improves the general cleanliness of turbines, but it is not fully clear if a FFA provides benefits on the mitigation of salt deposits in the steam turbine.

If the pH does not depress below the shutdown limit, then to counteract the effect of this corrosive chloride contaminant the dosing of the alkalizing agent, e.g., FFAP blended with neutralizing amines, should be increased while increasing the boiler blowdown rate. Neutralizing agents will help to neutralize the acid generated by the chloride contaminant,

and higher boiler blowdown will help to reduce the accumulation of chloride contamination in the boiler/evaporator water. It is important to ensure sufficient buffering is achieved, as an extreme low pH will risk under-deposit corrosion [59]. Of course the boiler/HRSG should be shut down with the pH dropping below 8, and, as with phosphate (PT) or NaOH (CT) additions in conventional treatments, the chloride remains in the boiler/evaporator and is equally harmful in the alkalized form. As a general rule, the concentration of FFAP blended with neutralizing amines should be temporarily increased until boiler water pH recovers to at least 9.0. Once the pH reaches 9.0, the dosing of FFAP blended with neutralizing amines can be gradually normalized as long as the leak has been eliminated.

The boiler/HRSG internals should be inspected as soon as possible after the event. Particular emphasis should be given to whether the boiler/HRSG internals are found to be hydrophobic in nature due to the fact that FFA can protect metal surfaces against corrosive chloride. Depending on the seriousness of the chloride in-leakage, any steam turbine included in the cycle may also need to be chemically cleaned.

## **9.9 Shutdown and Layup**

During shutdown and layup, air ingress will lead to an accumulation of oxygen and carbon dioxide in the water/steam cycle. In water-filled areas, oxygen and carbon dioxide will be dissolved in the water. This can result in electrochemical corrosion. Additionally, the pH will be reduced by carbon dioxide, so the existing protective layer may not remain stable.

In drained and emptied areas, the oxygen may react with the surfaces if the relative humidity in the system is not kept below 30–40 % according the Vernon curve [72]. This can happen from the first minute of shutdown, so corrosion protection should start immediately during the shutdown process. The use of FFA/FFAP is an effective way to protect the main parts of the water/steam cycle against corrosion during these shutdown periods. With injection of a FFA before or during the shutdown, most of the internal surfaces should be covered with an amine-containing hydrophobic protective layer which remains stable during shutdown irrespective of whether the system is filled with water or not. As discussed in Section 5.5, the one exception may be the superheated steam circuits.

To customize the FFA application, there is a major difference between power plants in cycling and two-shifting operation, and those with continuous operational periods interspersed with long shutdown periods that might last for months.

Cycling operation is often characterized by short operation times with starts and stops daily, mostly unscheduled and often with short notice. The duration of the shutdown periods cannot be predicted. For these power plants, a continuous injection of FFA during operation is preferable because of the short time of operation. Depending on the chosen FFAP (Sections 8.3 and 8.4), the injection has to be made in addition to the normal water chemistry or as a substitute to the conventional chemicals.

Power plants with longer shutdown periods, which need to be able to return to service within a short time period, should increase the dosage prior to shutdown so that a higher concentration of FFA can be measured in the water. During the shutdown period, the water

should be recirculated and the following parameters measured in the water once every two weeks. The trend of the data is more important than the absolute value:

- pH;
- Conductivity;
- FFA concentration;
- Chloride and sulfate;
- Total Iron;
- Total Copper (in cases where copper alloys are used).

A specific value for total iron and total copper cannot be given, since iron and copper uptake of the water is dependent on the metal / metal-oxide surface to water volume ratio.

In cases when the FFA concentration drops below the value specified by the supplier, additional product should be dosed and the water recirculated.

The conservation of the equipment in the water/steam cycle can be supported by an increase of pH in the water.

The film on the surfaces does not need to be removed before returning the plant to normal operation. The water chemistry should be returned to the normal operational conditions. In the case that the water level in the boiler, e.g., in the drum, has been increased, the water should be drained to the normal level of operation. Furthermore, the dosage of FFAP should be reduced or stopped until the measurable FFA concentration is within the desired range for continuous operation (Section 8.3). This can be accelerated by a temporary increase of water discharge. The cycle chemistry parameters should return to normal levels, typically within one week, during which time the parameters should be carefully controlled.

When carrying out repair work, such as welding, the formation of fumes caused by the thermal decomposition of the FFA has to be taken into consideration, and suitable personal protection should be worn accordingly.

Power plants going into a planned shutdown/layup after a long period of continuous operation (for example for seasonal reasons such as heating plants, sugar industry, capacity reserve) do not need a continuous injection of FFAP. To make sure that all areas of the water/steam cycle are covered with a protective amine layer, the injection of the FFAP has to start at a defined period before the shutdown. This period depends on the chosen FFAP, the design of the water/steam cycle, and the steam capacity. Also in this case the maximum concentration is commonly higher than during continuous FFA treatment (Sections 8.3 and 8.6). Plant protection is complete when the specified concentration of the FFA can be measured in the system for the specified period of time.

Power plants with a condensate polishing plant should bypass it during the FFA application, as the cation ion exchange resin will remove the FFA and alkalizing amine molecules from the condensate. Even though the FFA will not damage the resin or cause a loss of capacity, a higher amount of FFA will be needed.

In the case where a plant is applying a FFA for preservation only, the film established on the surface will be slowly removed during normal operation. The influence of the removed film on cycle chemistry is negligible. Laboratory data performed with conductivity probes showed that the coating effect caused by FFAP was washed away shortly after stopping the addition of the FFAP. However, ORP probes lost their sensitivity and response time irreversibly after one exposure to FFAP [57].

Plants that are to be emptied for preservation should be drained warm and dried as much as possible by the residual heat from the plant. Draining temperature, therefore, should be as high as possible. The control of preservation can be done visually. After draining, the surfaces should show a hydrophobic, water-repellant character, which should remain during the shutdown period. For these dry layup situations, there is not enough information available on how long the film will last. Good preservation of the metal surfaces has been obtained in practice [13, 40] and in the laboratory [41] for more than one year.

### **9.10 Systems Containing Condensate Polishing Plants (CPP)**

Ion exchange resins are important to achieve the desired high water purity needed for the proper operation of the water/steam cycle. Therefore, it is important for the user to know the impact of FFA on ion exchange resins.

A few papers have been published on experiences with a CPP as part of water/steam cycles treated with film forming amines [26, 48, 73]. They describe proper operation of the CPP. A decrease in the regeneration frequency has been reported [26] after the change of a conventional AVT treatment program to FFA, but the reason for this was not mentioned. Diminished cation exchange resin capacity in the CPP was reported, which was attributed to resin fouling by hydrocarbons [71].

Laboratory studies on the impact of FFA on ion exchange resins show that the FFA molecules are almost completely removed by the strongly acidic cation resin [74, 75] and are removed from the resin by the normal regeneration process. High FFA dosages led to a reduction of total cation ion exchange capacity [75] and mass transfer coefficient, which could be recovered by an additional regeneration. Regeneration of a resin exposed to ODA could not fully recover exchange capacity.

Due to the variety of FFAP compositions, a general statement on the impact of FFAP on the functionality of a CPP cannot be provided. Therefore, in the case where a FFAP is intended to be continuously applied in a water/steam cycle, operators should request technical information related to the interaction of the components with the CPP from the supplier of the FFAP, in order to be able to judge whether there would be a risk related to the application of the FFAP. The key indices of the CPP performance should be monitored as a baseline according to the principles outlined in Sections 8.2 and 8.6 of this TGD before the change to the FFA-based treatment and compared to the same indices determined in an analogous way when the FFAP is applied.

If a power plant equipped with a condensate polishing unit intends to apply a FFA/FFAP for preservation during a shutdown only, the CPP should be bypassed during the period of

FFA/FFAP dosage. Generally, in this case the operator will need to apply high dosages of FFA/FFAP in order to establish the protective film on the surfaces (see Section 9.9).

### **9.11 General Comments on Industrial Power Plants**

This TGD addresses the use of film forming amines in the water/steam cycles of fossil, combined cycle, and biomass power plants. However, there are numerous industrial steam raising plants successfully applying FFA/FFAP in the water/steam cycles. Industrial water/steam cycles frequently are characterized by long and branched condensate systems, often several systems interconnected, and thus there is a risk for severe corrosion problems, which might deteriorate condensate quality and cause further problems due to metal oxide transport. Due to the film forming property, FFA can provide good protection to these kinds of systems against oxygen corrosion and lack of local pH control.

A comprehensive description of all the equipment and operating details of industrial water/steam cycles far surpasses the scope of this TGD. However, the general procedures and guidance given in Section 8 can be customized for industrial applications. Especially the procedures delineated in Sections 8.2 (What does an Operator need to do before Applying a FFA/FFAP?), 8.5 (How to Analyze the Content of FFA within the Cycle), and 8.6 (Determining Optimum Usage) can be used. The specific parameters and performance indicators, however, might need to be adapted to the plant details for specific processes and level of integration into industrial complexes. Furthermore, the other customizations in Section 9 provide important information for the operators of industrial plants.

## 10 Bibliography and References

1. IUPAC, *Quantities, Units and Symbols in Physical Chemistry*, 3rd Edition (RSC Publishing, 2007).
2. IAPWS, TGD1-08, *Technical Guidance Document: Procedures for the Measurement of Carryover of Boiler Water into Steam* (2008). Available from <http://www.iapws.org>.
3. IAPWS, TGD2-09(2015), *Technical Guidance Document: Instrumentation for Monitoring and Control of Cycle Chemistry for the Steam-Water Circuits of Fossil Fired and Combined Cycle Power Plants* (Original 2009; Revision 2015). Available from <http://www.iapws.org>.
4. IAPWS, TGD3-10(2015), *Technical Guidance Document: Volatile Treatments for the Steam-Water Circuits of Fossil and Combined Cycle/HSRG Power Plants* (Original 2010; Revision 2015). Available from <http://www.iapws.org>.
5. IAPWS, TGD4-11(2015), *Technical Guidance Document: Phosphate and NaOH Treatments for the Steam - Water Circuits of Drum Boilers in Fossil and Combined Cycle / HSRG Power Plants* (Original 2011; Revision 2015). Available from <http://www.iapws.org>.
6. IAPWS, TGD5-13, *Technical Guidance Document: Steam Purity for Turbine Operation* (2013). Available from <http://www.iapws.org>.
7. IAPWS, TGD6-13(2014), *Technical Guidance Document: Corrosion Product Sampling and Analysis for Fossil and Combined Cycle Plants* (2014). Available from <http://www.iapws.org>.
8. Betova, I., Bojinov, M., and Saario, T., *Film-Forming Amines in Steam/Water Cycles – Structure, Properties and Influence on Corrosion and Deposition Processes*, Research Report VTT-R-03234-14, Technical Research Centre of Finland (VTT), 2014.
9. European Patent EP0065609B1; Moran, F., Rocher, S., and Duprat, M., *Composition inhibitrice de corrosion, son procédé de préparation et son application dans le domaine de la protection des surfaces métalliques* (1981).
10. European Patent EP0774017B1; Moran, F., *Scale and corrosion inhibition composition for protecting surfaces in contact with water and method for preparation of said composition* (1995).
11. Hater, W., and de Bache, A., Film Forming Amines in Boiler Feed Water Treatment, *IPW (Int. Paper World)* 10-11, 12 (2010).
12. RÖMPP (Dill, B., Böckler, F., and Kirschning, A., eds.), *Georg Thieme Verlag KG* (Stuttgart, Germany, 2008) <https://roempp.thieme.de/>, accessed on April 11, 2016.
13. Hater, W., de Bache, A., and Petrick T., Dry Lay-up of Steam Generators with Film Forming Amines: Studies and Field Experiences, *PowerPlant Chemistry* **16**(5), 284-292 (2014).
14. Duprat, M., Lafont, M.-C., and Dabosi, F., Study of the Corrosion and Inhibition Processes of a Carbon Steel in a Low Conductivity Medium by Electrochemical Methods, *Electrochim. Acta* **30**, 353-365 (1985).

15. Foret, C., Stoianovic, G., Chaussec, G., de Bache, A., zum Kolk, C., and Hater, W., Study of Efficiency and Stability of Film Forming Amines (FFA) for the Corrosion Protection of the Carbon Steel in Water Circuits, *EUROCORR 2008*, Edinburgh, UK, Paper 1404 (2008).
16. Öztürk, I., and Sezer, F., Investigation the Effect of Film Forming Amines on the Corrosion Inhibition of Carbon Steel, *EUROCORR 2011*, Stockholm, Sweden, paper 4520 (2011).
17. Kuang, W., Lee, S.-K., Mathews, J.A., and Macdonald, D.D., Monitoring Crevice Corrosion via the Coupling Current Part II: The Effect of Anodamine, *PowerPlant Chemistry* **15**(5), 356-365 (2013).
18. Couvidat, P. and Blériot, P., Mise en Évidence de l'Amélioration du Rendement Thermique de Générateurs de Vapeur par un Traitement à l'Aide d'Amines Filmantes Grâce à la Mise en Place de l'Enregistrement des Paramètres, *Proceedings of Journées information des eaux*, Poitiers, France, 09. 25-27, paper no. 64 (2012).
19. Janssen, P., and Savelkoul, J., In Search of an Alternative High Pressure Boiler Treatment Program, *PowerPlant Chemistry* **14**(7), 440 (2012).
20. Sylwestrzak, E., Moszczynski, W., Hater, W., Dembowski, T., and de Bache, A., Experiences with the Treatment of the Water / Steam Cycle of the Adamów Power Plant with Film Forming Amines; Proceedings of the VGB Conference 'Chemistry in Power Plants', Berlin, Germany (2015).
21. Hater, W., Digiario, C., and Frayne, C., Film Forming Amines - An Innovative Technology for Boiler Water Treatment, *Proc. International Water Conf. 2012*, Paper IWC12-20 (2012).
22. Petrova, T.I., Kashinsky, V.I., Zonov, A.A., and Trishin, E.P., Removal of Deposits from the Turbine Flowpath at Sakhalinskaya Power Plant using a Filming Amine, *PowerPlant Chemistry* **2**(10), 601 (2000).
23. Denk, J., and Svoboda, R., Stress Corrosion Cracking due to Carbon Dioxide and Organic Impurities in the Steam-water cycle, EPRI TR-1013630; *Proceedings 2006: International Conference on the Interaction of Organics and Organic Cycle Treatment Chemicals with Water, Steam and Materials*. Also published with same title in *PowerPlant Chemistry* **8**(7), 401 (2006).
24. Bäbller, R., Beitrag zur Charakterisierung der Inhibierenden Wirkung von Octadecylamin auf die Korrosion des Stahles, 1.5541 bis 250 °C, Doctoral Thesis, TU Dresden (1997).
25. Frahne, D., and Blum, T., Formation of Polyamine Films on Iron Surfaces under Power Plant Conditions – Laboratory Investigations, *PowerPlant Chemistry* **8**(1), 21-30 (2006).
26. van Lier, R., Janssen G., and Savelkoul, J., Three Years of Experience with Polyamines in the High Pressure Steam System of a Naphtha Cracker, *PowerPlant Chemistry* **10**(12), 696 (2008).
27. Haynes, W.M., ed., *CRC Handbook of Chemistry and Physics*, 92nd edition (CRC Press, Boca Raton, FL, 2011-2012).
28. Hater, W., and de Bache, A., Considerations on Conductivity and pH in Water/Steam Cycles using Organic Cycle Chemistry, *PowerPlant Chemistry* **15**(4), 289 (2013).



29. Jack, M., Weerakul, S., and Lister, D.H., The Interaction of a Film Forming Amine with Surfaces of a Recirculating Experimental Water Loop, *Proceedings International Conference on Heat Exchanger Fouling and Cleaning*, Enfield, Dublin, Ireland. 2015 June 7-12.
30. Bohnsack, G., Korrosionsinhibierung durch das im Helamin enthaltene "filmbildende Amin", *VGB Kraftwerkstechnik* **77**, 841 (1997).
31. Filippov, G.A., Saltanov, G.A., and Kukushkin, A.N., Hydrodynamics and Heat-Mass Transfer with Presence of Surface Active Substances (Energoatomizdat, Moscow, USSR, 1988).
32. Dubrovsky, A.Ya., Eskin, N.B., Tugov, A.N., and Anikeev, A.V., Adsorption of Octadecylamine on Boiler Steels in Subcritical Once-Through Boiler, *Teploenergetika*, (7), 24-28 (2003).
33. Petrick, T., Untersuchungen zur Adsorption von Oligoalkylaminofettaminen auf Metalloberflächen, Diploma Thesis, University Zittau/Görlitz (2013).
34. Gasnier, C., and Lister, D.H., The Effects of Chemical Additives on Magnetite Deposition in Boiling Heat Transfer. *Proceedings International Conference on Heat Exchanger Fouling and Cleaning*, Budapest, Hungary, 2013 June 9-14.
35. Gao, S., Hu, J., Xie J., Liang, Q., and Yin, L., Research on the Film Forming Characteristics of Octadecylamine at High Temperatures, *Anti-Corrosion Methods and Materials* **60**, 14 (2013).
36. Ochoa, N., Moran, F., and Pébère, N., The Synergistic Effect Between Phosphonocarboxylic Acid Salts and Fatty Amines for the Corrosion Protection of a Carbon Steel, *J. Appl. Electrochem.* **34**, 487-493 (2004).
37. Ochoa, N., Moran, F., Pébère, N., and Tribollet, B., Influence of Flow on the Corrosion Inhibition of Carbon Steel by Fatty Amines in Association with Phosphonocarboxylates, *Corrosion Sci.* **47**, 593 (2005).
38. Allard, B., Chakraborti, S., and Kannappan, A., Boiler Water Treatment with Polyamines, *Kemisk Tidskrift* **9**, 107 (1982).
39. Allard, B., and Chakraborti, S., Controlling Corrosion and Scaling with Aliphatic Amines in Steam Generator Systems, *Svensk Pappertidning* **86**, R186 (1983).
40. Langner, A., and Rziha, M., Experience with Octadecylamine for the layup of water steam cycles (CCPP Gilan); *Proceedings 3<sup>rd</sup> Int. VGB/EPRI Conference on Steam Chemistry*, Freiburg, Germany (1999).
41. Hater, W., and de Bache, A., Update of Layup of Steam Generators with Film Forming Amines; *Proceedings of 2<sup>nd</sup> Meeting of European HRSG Forum*, Munich (2015).
42. Voges, N., and Hater, W., Distribution Ratio and Average Surface Coverage of Film-Forming Amines, *PowerPlant Chemistry* **12**(3), 132-138 (2010).
43. *Organic Plant Cycle Treatment Chemicals - A Power Plant Chemistry Interview*, *PowerPlant Chemistry* **11**(8), 468 (2009).
44. Moed, D.H., Verliefde, R.D., and Rietveld, L.C., Effects of Temperature and Pressure on the Thermolysis of Morpholine, Ethanolamine, Cyclohexylamine, Dimethylamine, and 3-Methoxypropylamine in Superheated Steam, *Ind. Eng. Chem. Res.* **54**, 2606 (2015).

45. Roofthoof, R., Bohnsack, G., and De Caluwe, R., The Behaviour of Certain Conditioning Agents in a Boiler at High Temperature, *Fifth International Conference Cycle Chemistry in Fossil Plants*, EPRI, June 10-12, 1997.
46. Soellner, A., Glueck, W., Hoellger, K., Hater, W., and de Bache, A., Comparison of Four Steam Generators Regarding the Decomposition Products of Amines, *VGB PowerTech* **3**, 61 (2013).
47. Kolander, B., de Bache, A., and Hater, W., Experience with Treating the Water/Steam Cycle in the Nehlsen Stavenhagen RDF Power Plant with Film-Forming Amines, *PowerPlant Chemistry* **15**(2), 137 (2013).
48. Schreiber, G., Dreßler, D., de Bache, A., Choschzick, H., and Hater, W., Wechsel der Behandlung des Wasser/Dampf-Kreislaufes in einem GuD Kraftwerk mit Fernwärmeauskopplung von Sauerstoffbinder/Ammoniak auf filmbildende Amine; *Proc. VGB Conference Chemistry in Power Plants*, Hamburg (2012).
49. Topp, H., Steinbrecht, D., Hater, W., and de Bache, A., The Influence of Film-Forming Amines on Heat Transfer during Saturated Pool Boiling, *PowerPlant Chemistry* **12**(7), 388-395 (2010).
50. Qin, S., Yunren, Q., and Qing, X., Effect of Additives on Flow Boiler Heat Transfer, *J. Chem. Ind. Engineering (China)* **46**, 81 (1995).
51. Obrecht, M.F., Filming Amine Inhibitors Control Corrosion, Improve Heat Transfer in Steam Heating Systems, *Heating, Piping, & Air Conditioning*, (11), 121-128 (1959).
52. Steinbrecht, D., Sind Amine eine Alternative zu herkömmlichen Konditionierungen für Wasser-Dampf-Kreisläufe?, *VGB PowerTech* **83**(9), 120 (2003).
53. Topp, H., Hater, W., de Bache, A., and zum Kolk, C., Film-Forming Amines in Shell Boilers, *PowerPlant Chemistry* **14**(1), 38-48 (2012).
54. Wagner, E., Influence of Temperature on Electrical Conductivity of Diluted Aqueous Solutions, *PowerPlant Chemistry* **14**(7), 455 (2012).
55. Lendi, M., Wagner, H., and Wuhrmann, P., pH Calculation by Differential Conductivity Measurement in Mixtures of Alkalization Agents, *PowerPlant Chemistry* **16**(1), 4-11 (2014).
56. Verheyden, K.S., Ertryckx, R.A.M., De Wispelaere, M., and Poelemans, N., Belgian Experience with Film Forming and Neutralizing Amines, *PowerPlant Chemistry* **5**(9), 516 (2003).
57. Lendi, M., and Wuhrmann, P., Impact of Film-Forming Amines on the Reliability of Online Analytical Instruments, *PowerPlant Chemistry* **14**(9), 560-567 (2012).
58. Dooley, R.B., and Shields, K.J., Using Corrosion Product Transport as a Metric for Feedwater Treatment Efficacy in Fossil Plants, *PowerPlant Chemistry* **17**(5), 296-305 (2015).
59. Dooley, R.B., and Bursik, A., Hydrogen Damage, *PowerPlant Chemistry* **12**(2), 122-127 (2010).
60. Dooley, R.B., and Bursik, A., Caustic Gouging, *PowerPlant Chemistry* **12**(3), 188-192 (2010).

61. Dooley, R.B., and Bursik, A., Acid Phosphate Corrosion, *PowerPlant Chemistry* **12**(6), 368-372 (2010).
62. IAPWS, TGD7-16, *Technical Guidance Document: HRSG High Pressure Evaporator Sampling for Internal Deposit Identification and Determining the Need to Chemical Clean* (2016). Available from <http://www.iapws.org>.
63. Dooley, R.B., Flow-accelerated Corrosion in Fossil and Combined Cycle/HRSG Plants, *PowerPlant Chemistry* **10**(2), 68-89 (2008).
64. Dooley, R.B., Aspden, A.G., Howell, A.G., and du Preez, F., Assessing and Controlling Corrosion in Air-cooled Condensers, *PowerPlant Chemistry* **11**(5), 264-274 (2009).
65. Long-Chain Fatty Amines: Spectrophotometric Method, British Standards Institution, London, United Kingdom, BS 2690: Part 117:1983 (1983).
66. Milun, A., and Moyer, F., Determination of Traces of Fatty Amines in Water, *Anal. Chem.* **28**, 1204 (1956).
67. European Patent EP0562210A1; Graf, A., *Method for the Determination of Polyamines*, 1993.
68. Stiller, K., Wittig, T., and Urschey, M., The Analysis of Film-Forming Amines – Methods, Possibilities, Limits and Recommendations, *PowerPlant Chemistry* **13**(10), 602-611 (2011).
69. Lendi, M., Continuous Photometric Determination of Film-Forming Amines, *PowerPlant Chemistry* **17**(1), 8-13 (2015).
70. Hoock, B., Hater, W., and de Bache, A., Thirteen Years of Experience with the Treatment of the Water-Steam Cycle of the MVV Enamic Power Plant with Film-Forming Amines, *PowerPlant Chemistry* **17**(5), 283-293 (2015).
71. van Lier, R., Cuoq, F., Peters, R., and Savelkoul, J., Ten Years of Experience with Polyamines in the High-Pressure Steam System of a Naphtha Cracker, *PowerPlant Chemistry* **17**(6), 356-363 (2015).
72. Vernon, W.H.J., A laboratory study of the atmospheric corrosion of metals. Part II.—Iron: the primary oxide film. Part III.—The secondary product or rust (influence of sulphur dioxide, carbon dioxide, and suspended particles on the rusting of iron), *Trans. Faraday Soc.* **31**, 1668-1700 (1935).
73. Vogt, T., Besl, G., and Stecklina, M., Change in Power Cycle Chemistry from Hydrazine/Phosphate to Amine/Polyamine Treatment in an Industrial Power Station, *PowerPlant Chemistry* **9**(8), 500 (2007).
74. EPRI Report 1003624: Identification and Testing of Amines for Steam Generator Chemistry and Deposit Control; November 2003, Part 2.
75. Savelkoul, J., Osterholt, F., van Lier, R., and Hater, W., The influence of film forming amines on the exchange behaviour of condensate polishing resins, *VGB PowerTech* **8**, 76 (2014).